

Carter Sanford Component Plant 298 Harvey Faulk Rd Sanford, NC 27332

Phone #:919-775-1450



Model: Pleasant Plains Community

Church Reno



1. The Placement Plan is a diagram for truss installation. It is not an engineered drawing and has not been reviewed by an engineer. The Owner/Building Designer is responsible for obtaining an engineer's review if one is required by the local jurisdiction.

2. The responsibilities of the Owner, Contractor, Building Designer, Component Designer and Component Manufacturer shall be as set forth in ANSI/TPI 1. Capitalized terms shall be as defined in ANSI/TP 1 unless otherwise indicated.

3. Each Component is designed as an individual component utilizing information provided by others. The Owner/Building Designer is responsible for reviewing all Component Submittal Packages and individual Component Design Drawings for compliance with the Construction Documents and compatibility with the overall Building design.

4. Contractor will not proceed with component installation until the Owner/Building Designer has reviewed the Component Submittal Package. Questions on the suitability of any Component will be resolved by the Building Designer.

5. The Building Designer and Contractor are responsible for all temporary and permanent bracing.

6. The Placement Plan assumes the building is dimensionally correct, structurally sound, and in a suitable condition to support each Component during installation and thereafter, including but not limited to installation of all bearing points. Proper design and construction of all structural components, including foundations, headers, beams, walls and columns are the responsibility of the Owner, Building Designer and Contractor.

7. Do not cut, drill, or modify any Component without first consulting the Component Manufacturer or Building Designer. Damaged Components shall not be installed unless directed by the Building Designer or approved by the Component Manufacturer.

8. Components must be handled and installed following all applicable safety standards and best practices, including but not limited to BCSI, OSHA, TPI and local codes. Failure to properly handle, brace or otherwise install Component can result in serious injury or death.

9. All uplift connectors shown within these documents are recommendations only. Per ANSI/TPI 1, all uplift connectors are the responsibility of the building designer and or contractor.

Approved By: Du W. W. D.

Date: 06-02-2025

Truss Drawing Left End Indicator End Indicator Holijar Styneol, hear end of truss indicates left end of truss as shown on individual truss drawings.

\*\* All uplift connectors shown within these documents are recommendations only. Per ANSI/TPI 1, all uplift connectors are the responsibility of the bidg designer and or cont

**Pleasant Plains Community** Church Reno-Roof-Church Reno ROOF PLACEMENT PLAN



00/00/00	00/00/00	00/00/00	00/00/00	00/00/00	Revisions
Name	Name	Name	Name	Name	ions

Seneral Notes: "CUTTING

Walk In Customer



### **Trenco**

818 Soundside Rd Edenton, NC 27932

Re: 25050178-01

Pleasant Plains Community Church Reno-Roof-Church Reno

The truss drawing(s) referenced below have been prepared by Truss Engineering Co. under my direct supervision based on the parameters provided by Carter Components (Chesapeake, VA).

Pages or sheets covered by this seal: I73736632 thru I73736632

My license renewal date for the state of North Carolina is December 31, 2025.

North Carolina COA: C-0844



May 26,2025


Gilbert, Eric

IMPORTANT NOTE: The seal on these truss component designs is a certification that the engineer named is licensed in the jurisdiction(s) identified and that the designs comply with ANSI/TPI 1. These designs are based upon parameters shown (e.g., loads, supports, dimensions, shapes and design codes), which were given to MiTek or TRENCO. Any project specific information included is for MiTek's or TRENCO's customers file reference purpose only, and was not taken into account in the preparation of these designs. MiTek or TRENCO has not independently verified the applicability of the design parameters or the designs for any particular building. Before use, the building designer should verify applicability of design parameters and properly incorporate these designs into the overall building design per ANSI/TPI 1, Chapter 2.

Job	Truss	Truss Type	Qty	Ply	Pleasant Plains Community Church Reno-Roof-Church
25050178-01	A01	Scissor	22	1	Job Reference (optional)

Carter Components (Chesapeake), Chesapeake, VA - 23323

Run: 8.73 S Feb 19 2025 Print: 8.730 S Feb 19 2025 MiTek Industries, Inc. Fri May 23 15:03:19 ID:ZhNXOF74RihBKxT8AhPdwozE 3q-RfC?PsB70Hq3NSgPqnL8w3uITXbGKWrCDoi7J4zJC?f Page: 1



Scale = 1:89.5

Plate Offsets	(X, Y)	: [2:0-1	-14,0-4-10],	[14:0-1	1-14,0-4-10]
---------------	--------	----------	--------------	---------	--------------

rate oneste (A) (). [2.5 + 1.15 + 1.5]													
Loading TCLL (roof) Snow (Pf) TCDL	(psf) 20.0 20.0 10.0	Spacing Plate Grip DOL Lumber DOL Rep Stress Incr	2-0-0 1.15 1.15 YES	CSI TC BC WB Matrix-MSH	0.90 0.58 0.78	DEFL Vert(LL) Vert(CT) Horz(CT)	in -0.54 -1.09 0.61	(loc) 20 19-20 14	l/defl >999 >550 n/a	240	PLATES MT20 MT20HS	<b>GRIP</b> 244/190 187/143	
BCLL BCDL	0.0* 10.0	Code	1002010/11 12014	Wadix Worr							Weight: 361 lb	FT = 20%	

#### LUMBER

TOP CHORD 2x6 SP No.2 BOT CHORD 2x6 SP 2400F 2.0E

2x4 SP No.3 \*Except\* 20-8:2x4 SP No.2 WEBS Left 2x6 SP No.2 - 3-6-0, Right 2x6 SP No.2 SLIDER

-3-6-0

BRACING TOP CHORD Structural wood sheathing directly applied or 1-9-2 oc purlins.

Rigid ceiling directly applied or 10-0-0 oc **BOT CHORD** 

bracing.

WEBS 1 Row at midpt 9-20, 7-20 2=0-3-8, 14=0-3-8 REACTIONS (size) Max Horiz 2=-175 (LC 15)

Max Uplift 2=-226 (LC 14), 14=-226 (LC 15)

Max Grav 2=2087 (LC 1), 14=2087 (LC 1)

(lb) - Maximum Compression/Maximum **FORCES** Tension

TOP CHORD 1-2=0/32, 2-4=-5678/635, 4-5=-6411/657,

5-7=-5724/577, 7-8=-4744/508, 8-9=-4744/508, 9-11=-5724/577 11-12=-6411/599, 12-14=-5678/526,

14-15=0/32

2-24=-684/5139, 23-24=-695/5216 **BOT CHORD** 21-23=-636/6000, 20-21=-408/5303,

19-20=-308/5303, 17-19=-406/6000, 16-17=-416/5216, 14-16=-407/5139

8-20=-208/3215, 9-20=-1202/300, 9-19=-32/504, 11-19=-768/244,

11-17=-35/162, 12-17=-32/828, 12-16=-247/96, 7-20=-1202/292, 4-24=-247/104, 4-23=-13/828, 5-23=-35/162,

5-21=-768/234, 7-21=-27/504

#### NOTES

WEBS

1) Unbalanced roof live loads have been considered for this design.

- 2) Wind: ASCE 7-16; Vult=130mph (3-second gust) Vasd=103mph; TCDL=6.0psf; BCDL=6.0psf; h=25ft; Cat. II: Exp B; Enclosed; MWFRS (envelope) exterior zone and C-C Exterior(2E) -1-4-8 to 3-7-10, Interior (1) 3-7-10 to 20-0-8, Exterior(2R) 20-0-8 to 30-0-12, Interior (1) 30-0-12 to 46-5-10, Exterior(2E) 46-5-10 to 51-5-12 zone; cantilever left and right exposed; end vertical left and right exposed; C-C for members and forces & MWFRS for reactions shown; Lumber DOL=1.60 plate grip DOL=1.60
- TCLL: ASCE 7-16; Pr=20.0 psf (roof LL: Lum DOL=1.15 Plate DOL=1.15); Pf=20.0 psf (Lum DOL=1.15 Plate DOL=1.15); Is=1.0; Rough Cat B; Fully Exp.; Ce=0.9; Cs=1.00; Ct=1.10
- Unbalanced snow loads have been considered for this design.
- This truss has been designed for greater of min roof live load of 12.0 psf or 1.00 times flat roof load of 20.0 psf on overhangs non-concurrent with other live loads.
- All plates are MT20 plates unless otherwise indicated.
- All plates are 4x5 MT20 unless otherwise indicated.
- This truss has been designed for a 10.0 psf bottom chord live load nonconcurrent with any other live loads.
- \* This truss has been designed for a live load of 20.0psf on the bottom chord in all areas where a rectangle 3-06-00 tall by 2-00-00 wide will fit between the bottom chord and any other members.
- 10) Bearing at joint(s) 2, 14 considers parallel to grain value using ANSI/TPI 1 angle to grain formula. Building designer should verify capacity of bearing surface.
- 11) One H2.5A Simpson Strong-Tie connectors recommended to connect truss to bearing walls due to UPLIFT at jt(s) 2 and 14. This connection is for uplift only and does not consider lateral forces.
- 12) This truss is designed in accordance with the 2018 International Building Code section 2306.1 and referenced standard ANSI/TPI 1.

13) This truss has been designed for a moving concentrated load of 250.0lb live and 40.0lb dead located at all mid panels and at all panel points along the Top Chord, nonconcurrent with any other live loads.

LOAD CASE(S) Standard



May 26,2025


NAMENING - Verify design parameters and READ NOTES ON THIS AND INCLUDED MITER REPRENCE PAGE MIN-74.73 rev. 1/2/2/2/3 BEFORE USE.

Design valid for use only with MITek® connectors. This design is based only upon parameters shown, and is for an individual building component, not a truss system. Before use, the building designer must verify the applicability of design parameters and properly incorporate this design into the overall building design. Bracing indicated is to prevent buckling of individual truss web and/or chord members only. Additional temporary and permanent bracing is always required for stability and to prevent collapse with possible personal injury and property damage. For general guidance regarding the fabrication, storage, delivery, erection and bracing of trusses and truss systems, see ANSI/TP11 Quality Criteria and DSB-22 available from Truss Plate Institute (www.tpinst.org) and BrCSI Building Component Sarghet Information, available from the Structural Building Component Sarghet Information, available from the Structural Building Component Association (www.sb-accomponents.com) and BCSI Building Component Safety Information available from the Structural Building Component Association (www.sbcacomponents.com)





# **Symbols**

#### PLATE LOCATION AND ORIENTATION



Center plate on joint unless x, y offsets are indicated.
Dimensions are in ft-in-sixteenths.
Apply plates to both sides of truss and fully embed teeth.





\* Plate location details available in MiTek software or upon request.

#### PLATE SIZE

4 x 4

The first dimension is the plate width measured perpendicular to slots. Second dimension is the length parallel to slots.

### LATERAL BRACING LOCATION



Indicated by symbol shown and/or by text in the bracing section of the output. Use T or I bracing if indicated.

#### BEARING



Indicates location where bearings (supports) occur. Icons vary but reaction section indicates joint number/letter where bearings occur. Min size shown is for crushing only.


### **Industry Standards:**

ANSI/TPI1: National Design Specification for Metal

Plate Connected Wood Truss Construction.

DSB-22: Design Standard for Bracing.
BCSI: Building Component Safety Ir

Building Component Safety Information, Guide to Good Practice for Handling, Installing, Restraining & Bracing of Metal Plate Connected Wood Trusses. **Numbering System** 



JOINTS ARE GENERALLY NUMBERED/LETTERED CLOCKWISE AROUND THE TRUSS STARTING AT THE JOINT FARTHEST TO THE LEFT.

CHORDS AND WEBS ARE IDENTIFIED BY END JOINT NUMBERS/LETTERS.

## **Product Code Approvals**

ICC-ES Reports:

ESR-1988, ESR-2362, ESR-2685, ESR-3282 ESR-4722, ESL-1388

# **Design General Notes**

Trusses are designed for wind loads in the plane of the truss unless otherwise shown.

Lumber design values are in accordance with ANSI/TPI 1 section 6.3 These truss designs rely on lumber values established by others.

© 2023 MiTek® All Rights Reserved





MiTek Engineering Reference Sheet: MII-7473 rev. 1/2/2023



# Failure to Follow Could Cause Property Damage or Personal Injury

- Additional stability bracing for truss system, e.g. diagonal or X-bracing, is always required. See BCSI.
- Truss bracing must be designed by an engineer. For wide truss spacing, individual lateral braces themselves may require bracing, or alternative Tor I bracing should be considered.
- Never exceed the design loading shown and never stack materials on inadequately braced trusses.
- Provide copies of this truss design to the building designer, erection supervisor, property owner and all other interested parties.
- 5. Cut members to bear tightly against each other.
- Place plates on each face of truss at each joint and embed fully. Knots and wane at joint locations are regulated by ANSI/TPI 1.
- Design assumes trusses will be suitably protected from the environment in accord with ANSI/TPI 1.
- Unless otherwise noted, moisture content of lumber shall not exceed 19% at time of fabrication.
- Unless expressly noted, this design is not applicable for use with fire retardant, preservative treated, or green lumber
- Camber is a non-structural consideration and is the responsibility of truss fabricator. General practice is to camber for dead load deflection.
- Plate type, size, orientation and location dimensions indicated are minimum plating requirements.
- Lumber used shall be of the species and size, and in all respects, equal to or better than that specified.
- Top chords must be sheathed or purlins provided at spacing indicated on design.
- Bottom chords require lateral bracing at 10 ft. spacing, or less, if no ceiling is installed, unless otherwise noted.
- 15. Connections not shown are the responsibility of others.
- Do not cut or alter truss member or plate without prior approval of an engineer.
- 17. Install and load vertically unless indicated otherwise.
- Use of green or treated lumber may pose unacceptable environmental, health or performance risks. Consult with project engineer before use.
- Review all portions of this design (front, back, words and pictures) before use. Reviewing pictures alone is not sufficient.
- Design assumes manufacture in accordance with ANSI/TPI 1 Quality Criteria.
- The design does not take into account any dynamic or other loads other than those expressly stated.