


INSTRUCTION MANUAL

Standard Series Gas Griddle



WARNING

This manual contains important information regarding your unit. Please read this manual thoroughly prior to equipment set-up, operation and maintenance. Failure to comply with regular maintenance guidelines outlined in this manual may void the warranty.

If you smell gas, follow the instructions provided by the gas supplier. Do not try to light the

WARNINGS

- Do not touch any hot surfaces
- Do not immerse unit in liquid at any time
- Do not operate unattended
- Do not use this unit for anything other than intended use
- Do not use outdoors
- Always use on a firm, dry and level surface at least 12" from walls or any other obstruction
- Keep children and animals away from unit
- Any incorrect installation, alterations, adjustments and/or improper maintenance can lead to property loss and injury. All repairs should be done by authorized professionals only.
- If gas odor is detected, shut unit down at main shutoff valve and contact service company
- Do not store or use gasoline or other flammable vapors or liquids in the vicinity of this appliance
- Do not ship or store upside down
- This unit should be stored in a well ventilated area that contains no corrosive gases.
- Do not get this unit wet
- This product is for commercial use only

BEFORE INSTALLATION

- Installation of this device should be operated by professional technicians
- This device is suitable for an area whose altitude is 0-2,000 ft. If it is higher than this altitude, please contact the manufacturer.
- Installation of this unit should conform to provisions of gas safety, installation and usage
- This device should be kept at a minimum clearance of 4" away from non-combustible objects on both sides and 8" at the back (e.g. walls, windows etc.). Do not install on a flammable floor or around other combustible objects.
- This item is intended to sit on a solid and level floor

TO INSTALL

1. Level the device with a level gauge. The height can be adjusted by the adjustable feet.
2. The mounting position should be well-ventilated with proper hood exhaust system that will ensure that all the burnt gases produced during use are completely disposed of.
3. After installation, level the device and keep stable. Do not sway or tilt during operation.
4. A quick-acting gas shut off valve should be installed near the device where it's easily reached.
5. Make sure you are using the correct gas supply that is specified for this model. If the gas supply is not intended for this model, do not proceed with installation.
6. This unit is applicable to low pressure regulating valves only. High pressure regulating valves and medium pressure regulating valves are not to be used.
7. Check to make sure the connection pipe to the unit has no leaks
8. If the connecting pipe pressure is 10% higher or lower than the rated pressure, please install a pressure regulator.
9. After connecting the appliance to the gas system, check for leaks at joints and pipe fittings; to do so, use soapy water or a specific leak detector (spray).
10. Check the gas supply pressure after installation.
11. Gas supply pressure can be measured with a liquid-filled pressure gauge (e.g. a U-shaped pressure gauge, minimum

CODES AND STANDARDS

This item must be installed in accordance with:

In the United States:

State and local codes, or in the absence of local codes, with:

National Fuel Gas Code, ANSI-Z223.1/NFPA #54 (latest edition). Copies may be obtained from The American Gas Association Accredited Standards Committee Z223, @ 400 N. Capital St. NW, Washington, DC 20001 or the Secretary Standards Council, NFPA, 1 Batterymarch Park Quincy, MA 02169-7471.

NFPA Standard #96 Vapor Removal from Cooking Equipment, latest edition, available from the National Fire Protection Association, Batterymarch Park, Quincy, MA. In the commonwealth of Massachusetts, all gas appliances vented through a ventilation hood or exhaust system with a damper or with a power means of exhaust shall comply with 248 CMR.

In Canada:

Local codes:


CAN/CSA-B149.1 Natural Gas Installation (latest edition).

CAN/CSA-B149.2 Propane Installation Code (latest edition), available from the Canadian Gas Association 178 Rexdale Blvd., Etobicoke, Ontario Canada M9W 1R3.

The installer of this unit should be aware of state, county or local code for connecting this equipment to determine if an external regulator is required.

PRESSURE REGULATOR:

- All commercial cooking equipment must have a pressure regulator on the incoming gas line for safe and efficient operation. The regulator provided for this equipment can be used for both natural gas and liquid propane.
- Regulator specifications: $\frac{3}{4}$ " NPT inlet and outlet, factory adjusted for 4" WC Natural Gas standard and may be converted by qualified personnel to be used for Propane at 10" WC.
- Prior to connecting the regulator, check the incoming line pressure. The regulator can only withstand a maximum pressure of $\frac{1}{2}$ PSI (14" WC). If the line pressure is beyond this limit, a step down the regulator before the regulator provided will be required. The arrow on the bottom shows gas flow direction and should point downstream to the equipment.




Connection diagram

GAS CONVERSION:

Conversion from Natural Gas to Liquid Propane (LP) or vice versa should only be performed by the factory or an authorized service agent. In case of troubleshooting, ensure the correct orifice sizes of the tips have been provided. Orifice size is marked on the tip.

OPERATING INSTRUCTIONS AND CONTROLS

When turning on for the first time please be advised that it might take a little longer to ignite due to the air existing in the pipe. If the ignition does not light, turn off the ignition switch and wait 3 minutes to try again.



LIGHTING THE PILOT

The manifold units are equipped with standing pilots and each should be lit immediately after the gas is supplied to the equipment.

1. Before attempting to light the pilots, turn off the main gas valve to the equipment and wait 5 minutes to clear the gas.
2. Turn all gas control knobs to the off position.
3. Turn on control valve and light all pilots.
4. The pilot burner must be lit at the end of the tube. Hold an ignition source through the pilot light hole in the front panel at the pilot tube. When the flame ignites remove ignition source.
5. Turn off the main gas valve to shut down the equipment.

NOTE: Smoke appearing on initial use of the equipment is normal. This is a result of the anti-rust coating burning off. Allow the equipment to "burn in" for at least 15 minutes before the first use.

PILOT FLAME ADJUSTMENT:

The pilot flame on the equipment has been factory adjusted. When adjustment is necessary, adjust the pilot flames as small as possible but high enough to light the burner immediately when the burner valve is turned to the highest setting. Access to the pilot flame adjustment screw is obtained by removing the front panel.

BURNERS:

1. Connect the gas supply and ignite the pilot flame with a lighter. If the unit hasn't been used in a while or if this is the first lighting, ignition might take a little longer (about two or three minutes).
2. Press the corresponding valve knob of burner and turn 90 degrees counterclockwise.
3. When finished turn off main burner by rotating the knob clockwise to off position.

CLEANING - NOTE: It is important to clean and maintain the unit daily. Checking the unit daily can help avoid serious accidents. Stop using if there are problems with the unit. Check the condition of the unit before and after using.

Before using: Is the machine tilted?

Is the control panel damaged?

During use: Is there a strange smell or noise?

Is the flame color normal?

Any light back or flameout?


1. Before cleaning, please turn off all gas valves.
2. It is important to clean the burners and drip tray(s) regularly.
3. Clean the stainless steel surface with warm soapy water daily and rinse it dry. During cleaning, do not clean the stainless steel surface with abrasive detergent, brush or scraper etc. The residual iron scale may cause rusting.
4. Do not clean the surface with a chlorine cleanser (bleach, hydrochloric acid etc.). Do not clean the floor where the unit is installed with corrosive substances (e.g. KCL).
5. Clean off the dirt and debris on the burners and baffle regularly.
6. Do not modify the ventilation volume needed during combustion.
7. Accumulation of the iron substance (e.g. Material that formed by iron rust dissolving in water in the pipe, especially when the device is not used for a long time.). Therefore, to avoid accumulation of such substance, clean the food swill that is difficult to clean with stainless steel scraper or a brush containing no iron substances instead of steel brush.
8. Keep substances containing acidic ingredients (vinegar, lemon juice, spices, salt, etc.) away from the stainless steel components. Acidic vapor from these solutions will damage the surface of the device.
9. A complete cleaning every day will ensure good usage and extend the life of the unit. Clean the unit with a wet towel containing suds or a detergent, rinse it with water and dry it with a clean cloth. Do not clean the device with steel brush, which may cause rust. Keep parts that are made of iron dry or will rust.
10. Cleaning the stainless steel surface: grease stains can be wiped away with sponge.
11. To avoid rusting of the unit, please make sure that the residual salt inside or outside the device is cleared away.
12. After cleaning, to avoid short-time incomplete combustion, the fire hole of the burner should be clear.
13. Turn off the main gas valve if item is not going to be used for an extended period of time.
14. If item is not going to be used for an extended period of time, it is best to clean fully and store in a well ventilated area.

TROUBLESHOOTING

Before requesting any service on the unit, please check the following chart. Service calls resulting from lack of maintenance or misuse is not covered under the warranty and may also void the warranty. Please note that this guide serves only as a reference for solutions to common problems.

Problem	Possible Causes	Solution
The pilot flame can't be ignited	The gas pressure is too low	Adjust the relieve valve to increase pressure
	The nozzle is clogged	Unclog the nozzle
	The gas control valve is malfunctioning	Replace the gas control valve
Problem	Possible Causes	Solution
The pilot flame is on but the main burner can't be ignited	The gas pressure is too low	Adjust the relieve valve to increase pressure
	The main burner nozzle is clogged	Unclog the nozzle
	The gas control valve is defective	Replace the gas control valve
Problem	Possible Causes	Solution
It has a light-back sound when the gas supply is turned off	Wrong orifice size for the gas supply	Install proper orifice
	The damper is too open	Adjust the damper
	The gas pressure is too low	Adjust the relieve valve
	Gas pressure too low	Increase the gas pressure
Problem	Possible Causes	Solution
Burner not hot enough	Temperature control not set	Adjust for desired temperature
	Shutter or nozzle out of adjustment	Contact qualified technician for adjustment
	Damaged temperature control, burner or other internal component	Contact manufacturer for repairs


18" Standard Series Griddle, 1 Burner



18" Standard Series Griddle, 1 Burner

Diagram Number	Part Description	Quantity
1	Griddle plate assembly	1
2	Burner assembly	1
3	Side panel,right	1
4	Orifice - NG or LP	1
5	Gas valve	1
6	Pilot valve	1
7	Inlet gas pipe	1
8	Adjustable leg	4
9	Oil tray	1
10	Front panel	1
11	Knob	1
12	Side panel,left	1


24" Standard Series Griddle, 2 Burner



24" Standard Series Griddle, 2 Burner

Diagram Number	Part Description	Quantity
1	Griddle plate assembly	1
2	Burner assembly	2
3	Side panel,right	1
4	Orifice - NG or LP	2
5	Gas valve	2
6	Pilot valve	2
7	Inlet gas pipe	2
8	Adjustable leg	4
9	Oil tray	1
10	Front panel	1
11	Knob	2
12	Side panel,left	1


36" Standard Series Griddle, 3 Burner



36" Standard Series Griddle, 3 Burner

Diagram Number	Part Description	Quantity
1	Griddle plate assembly	1
2	Burner assembly	3
3	Side panel,right	1
4	Orifice - NG or LP	3
5	Gas valve	3
6	Pilot valve	3
7	Inlet gas pipe	3
8	Adjustable leg	4
9	Oil tray	1
10	Front panel	1
11	Knob	3
12	Side panel,left	1

48" Standard Series Griddle, 4 Burner



48" Standard Series Griddle, 4 Burner

Diagram Number	Part Description	Quantity
1	Griddle plate assembly	1
2	Burner assembly	4
3	Side panel,right	1
4	Orifice - NG or LP	4
5	Gas valve	4
6	Pilot valve	4
7	Inlet gas pipe	4
8	Adjustable leg	4
9	Oil tray	1
10	Front panel	1
11	Knob	4
12	Side panel,left	1

Admiral Craft Equipment Corp One Year Limited Warranty

Admiral Craft Equipment Corp warrants its equipment against defects in materials and workmanship, subject to the following conditions:

ONE YEAR WARRANTY

Admiral Craft Equipment Corp is warranted for one year, effective from the date of purchase by the original owner. A copy of the original receipt or other proof of purchase is required to obtain warranty coverage. This warranty applies to the original owner only, and is not assignable.

ADDITIONAL FRY POT WARRANTY

All Stainless Steel Fry Tanks have a (5) year limited tank warranty. If the tank has a leak under normal usage in the first year of operation, verified by an authorized service company, the entire fryer will be replaced. After the first year and for the following (4) years, a replacement tank will be sent at no charge. Shipping costs and labor charges to install the tank will be the end users responsibility.

Should any product fail to function in its intended manner under normal use within the limits defined in this warranty, at Admiral Craft Equipment Corp's discretion, such product will be repaired, replaced with a refurbished unit, or replaced with a new unit by Admiral Craft Equipment Corp, after defective unit has been inspected and defect has been confirmed. Admiral Craft Equipment Corp does not assume any liability for extended delays in replacing any item beyond its control. This warranty does not apply to rubber and non-metallic synthetic parts that may need to be replaced due to normal usage, wear or lack of preventative maintenance.

This warranty covers products shipped into the 48 contiguous United States. Warranty coverage on products used in Hawaii, Alaska, Puerto Rico, and Canada cover parts only.

Equipment installed in/on a food truck or trailer will be limited to a period of 30 days from the original date of purchase.

The following conditions are not covered by warranty:

- Equipment failure relating to improper installation, improper utility connection or supply and problems due to improper ventilation.
- Equipment that has not properly been maintained, damage from improper cleaning, and water damage to controls.
- Equipment that has not been used in an appropriate manner, or has been subject to misuse, neglect, abuse, accident, alteration, negligence, damage during transit, delivery or installation, fire, flood, riot, or act of God.
- Equipment that has the model number or serial number removed or altered.
- Equipment on which the security seal has been broken.

If the equipment has been changed, altered, modified, or repaired without express written permission from Admiral Craft Equipment Corp, then the manufacturer shall not be liable for any damages to any person or to any property, which may result from the use of this equipment thereafter.

This equipment is intended for commercial use only and this warranty is void if equipment is used in other than a commercial application. The manufacturer does not recommend or authorize the use of any product in a non-commercial application, including but not limited to residential use. The use or installation of any product in non-commercial applications renders all warranties, expressed or implied, including the warranties of merchantability and fitness for a particular purpose, null and void, including any responsibility for damage, costs and legal actions resulting from the use or installation of products in any non-commercial setting.

"THE FOREGOING WARRANTY IS IN LIEU OF ANY AND ALL WARRANTIES EXPRESSED OR IMPLIED INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSES AND CONSTITUTES THE ENTIRE LIABILITY OF ADMIRAL CRAFT EQUIPMENT CORP IN NO EVENT DOES THE LIMITED WARRANTY EXTEND BEYOND THE TERMS STATED HEREIN."