

We will use the existing header for the door opening and add an additional 2x4 to cover the span. We will then use (2) pressure treated 2x4's to span the bottom of the opening. We will attach (8) 2x4s to span the opening placing all except two at 16 inches O.C. and two of them being 12 in O.C. to compensate for the center of the wall and the uneven measure of the opening.

