



Matthew Pompey
1320 Fort Bragg Road
Fayetteville, NC 28305
August 20, 2018

Thank you for choosing A-1 Carolina Chimney Masters.

The chimney located in the home at 238 Chesapeake Rd, Cameron, NC 27326 has been brought up to code and is now safe to burn in.

Before burning in the new fireplace there are some processes that need to be followed to ensure proper curing of the new refractory fireback panels that were installed inside the fireplace. That process is as follows:

1. Burn for 30 minutes
2. Allow the panels to cool, 4-5 hours
3. Burn again for 30 minutes
4. Allow the panels to cool, 4-5 hours
5. Burn again for 45-60 minutes
6. Allow the panels to cool, 4-5 hours

At this point the fireplace is ready to be used. Some additional information on fireplace use is stated below.

The suggested size of your fire should be no more than 3 logs, 12-14 inches in length and 6 inches in diameter, burning at full burn of 1500° to 2200°.

Please ensure that a cleaning is performed annually to maintain the integrity of the fireplace and to maintain the warranty.

Sincerely,

Matthew C. Pompey

Matthew Pompey

Owner