

WELL ABANDONMENT RECORD

This form can be used for single or multiple wells

1. Well Contractor Information:

Justin Barefoot
Well Contractor Name (or well owner personally abandoning well on his/her property)

3974-A
NC Well Contractor Certification Number

Barefoot's well
Company Name

2. Well Construction Permit #: 17-5-41136
List all applicable well permits (i.e. County, State, Variance, Injection, etc.) if known

3. Well use (check well use):

Water Supply Well:

- Agricultural Municipal/Public
 Geothermal (Heating/Cooling Supply) Residential Water Supply (single)
 Industrial/Commercial Residential Water Supply (shared)
 Irrigation

Non-Water Supply Well:

- Monitoring Recovery

Injection Well:

- Aquifer Recharge Groundwater Remediation
 Aquifer Storage and Recovery Salinity Barrier
 Aquifer Test Stormwater Drainage
 Experimental Technology Subsidence Control
 Geothermal (Closed Loop) Tracer
 Geothermal (Heating/Cooling Return) Other (explain under 7g)

4. Date well(s) abandoned: 6-30-17

5a. Well location:

Charles Marshall Johnson
Facility/Owner Name Facility ID# (if applicable)

1173 Johnson Farm Rd
Physical Address, City, and Zip

Harnett
County Parcel Identification No. (PIN)

5b. Latitude and longitude in degrees/minutes/seconds or decimal degrees:
(if well field, one lat/long is sufficient)

35.4225 N - 78.7629 W

CONSTRUCTION DETAILS OF WELL(S) BEING ABANDONED

Attach well construction record(s) if available. For multiple injection or non-water supply wells ONLY with the same construction/abandonment, you can submit one form.

6a. Well ID#: _____

6b. Total well depth: 18 (ft.)

6c. Borehole diameter: 48 (in.)

6d. Water level below ground surface: 15 (ft.)

6e. Outer casing length (if known): 0 (ft.)

6f. Inner casing/tubing length (if known): 0 (ft.)

6g. Screen length (if known): 0 (ft.)

For Internal Use ONLY:

WELL ABANDONMENT DETAILS

7a. Number of wells being abandoned: 1
For multiple injection or non-water supply wells ONLY with the same construction/abandonment, you can submit one form.

7b. Approximate volume of water remaining in well(s): 0 (gal.)

FOR WATER SUPPLY WELLS ONLY:

7c. Type of disinfectant used: Chlorine

7d. Amount of disinfectant used: 1 pound

7e. Sealing materials used (check all that apply):

- Neat Cement Grout Bentonite Chips or Pellets
 Sand Cement Grout Dry Clay
 Concrete Grout Drill Cuttings
 Specialty Grout Gravel
 Bentonite Slurry Other (explain under 7g)

7f. For each material selected above, provide a amount of materials used:

A lot dry clay
7 Bag concrete cap

7g. Provide a brief description of the abandonment procedure:

8. Certification:

[Signature] Date 6-30-17
Signature of Certified Well Contractor or Well Owner

By signing this form, I hereby certify that the well(s) was (were) abandoned in accordance with 15A NCAC 02C .0100 or 2C .0200 Well Construction Standards and that a copy of this record has been provided to the well owner.

9. Site diagram or additional well details:

You may use the back of this page to provide additional well site details or well abandonment details. You may also attach additional pages if necessary.

SUBMITTAL INSTRUCTIONS

10a. **For All Wells:** Submit this form within 30 days of completion of well abandonment to the following:

Division of Water Resources, Information Processing Unit,
1617 Mail Service Center, Raleigh, NC 27699-1617

10b. **For Injection Wells:** In addition to sending the form to the address in 10a above, also submit one copy of this form within 30 days of completion of well abandonment to the following:

Division of Water Resources, Underground Injection Control Program,
1636 Mail Service Center, Raleigh, NC 27699-1636

10c. **For Water Supply & Injection Wells:** In addition to sending the form to the address(es) above, also submit one copy of this form within 30 days of completion of well abandonment to the county health department of the county where abandoned.