WELL ABANDONMI	ENT RECORD	For Internal Use ONLY:	EH1908-0015
1. Well Contractor Information:		WELL ADANDONMENT DETAIL CO.	
		WELL ABANDONMENT DETAILS	
Well Contractor Name (or well owner personally abandoning well on his/her property)		7a. For Geoprobe/DPT or Closed-Loop Geothermal Wells having the same well construction/depth, only 1 GW-30 is needed. Indicate TOTAL NUMBER of wells abandoned:	
NC Well Contractor Certification Number		7b. Approximate volume of water rem	naining in well(s): (gal.)
AM		FOR WATER SUPPLY WELLS ON	LV:
Company Name		7c. Type of disinfectant used:	
2. Well Construction Permit #:	e. UIC, County, State, Variance, etc.) if known	7d. Amount of disinfectant used:	- 14
3. Well use (check well use):		, strain of distinct and detail	
Water Supply Well:		7e. Sealing materials used (check all th	nat apply):
□Agricultural	□Municipal/Public	□ Neat Cement Grout	☐ Bentonite Chips or Pellets
☐Geothermal (Heating/Cooling Supply)	Residential Water Supply (single)	☐ Sand Cement Grout	□ Dry Clay
□Industrial/Commercial	☐Residential Water Supply (shared)	Concrete Grout	□ Drill Cuttings
□Irrigation	20050. 20 20 VBs	☐ Specialty Grout	□ Gravel
Non-Water Supply Well:		☐ Bentonite Slurry	☐ Other (explain under 7g)
☐Monitoring Injection Well:	□Recovery		
□ Aquifer Recharge	□Groundwater Remediation	7f. For each material selected above, provide amount of materials used:	
□ Aquifer Storage and Recovery			
□ Aquifer Test	□Salinity Barrier □Stormwater Drainage		
□Experimental Technology	□Subsidence Control		
Geothermal (Closed Loop)	□Tracer	7g. Provide a brief description of the abandonment procedure:	
□Geothermal (Heating/Cooling Return)	□Other (explain under 7g)		
4. Date well(s) abandoned: 8/3c			2517E
Jerry D. Grogery Facility/Owner Name	440	VE	elluming
Facility/Owner Name	Facility ID# (if applicable)	8. Certification:	ALLUM 1 2120
Physical Address, City, and Zip	Angio, NX 27501	Signature of Certified Well Contractor or Well	•
Hacrett	046(82 -011		
County	Parcel Identification No. (PIN)	By signing this form, I hereby certify that the well(s) was (were) abandoned in accordance with 15A NCAC 02C .0100 or 2C .0200 Well Construction Standards and that a copy of this record has been provided to the well supply	
5b. Latitude and longitude in degrees/minutes/seconds or decimal degrees: (if well field, one lat/long is sufficient)		and that a copy of this record has been provided to the well owner.  9. Site diagram or additional well details:	
N	w	You may use the back of this page to provide additional well site details or well abandonment details. You may also attach additional pages if necessary.	
CONSTRUCTION DETAILS OF WELL(S) BEING ABANDONED  Attach well construction record(s) if available. For multiple injection or non-water supply wells  ONLY with the same construction (about the same construction).		SUBMITTAL INSTRUCTIONS	
ONLY with the same construction/abandonment, you can submit one form.  6a. Well ID#:A		10a. For All Wells: Submit this form within 30 days of completion of well abandonment to the following:	
		Division of Water Resources, Information Processing Unit,	
6b. Total well depth: 6 - 8 (ft.)		1617 Mail Service Center, Raleigh, NC 27699-1617	
6c. Borehole diameter: 24(in.)		<b>10b.</b> For Injection Wells: In addition to sending the form to the address in 10a above, also submit one copy of this form within 30 days of completion of well abandonment to the following:	
6d. Water level below ground surface:(ft.)		Division of Water Resources, Underground Injection Control Program, 1636 Mail Service Center, Raleigh, NC 27699-1636	
6e. Outer casing length (if known):	~ ↑ (ft.)	10c. For Water Supply & Injection Wells: In addition to sending the form to the address(es) above, also submit one copy of this form within 30 days of completion of well abandonment to the county health department of the county where	
of. Inner casing/tubing length (if known):(ft.)		abandoned.	

6g. Screen length (if known): \_\_\_\_\_

\_\_\_\_(ft.)