This form can be used for single or multiple wells	For Internal Use ONLY:
1. Well Contractor Information:	WELL ABANDONMENT DETAILS
ROCER W. JACKSON	
Well Contractor Name (or well owner personally abandoning well on his/her property)	7a. Number of wells being abandoned:  For multiple injection or non-water supply wells ONLY with the same
* 2179	construction abandonment, you can submit one form.
NC Well Contractor Certification Number	7b. Approximate volume of water remaining in well(s):(gal.)
TACKON WELL CO	FOR WATER SUPPLY WELLS ONLY:
Company Name	-
2. Well Construction Permit #: 2179 EH1910 000 List all applicable well permits (i.e. County, State, Variance, Injection, etc.) if known	7c. Type of disinfectant used: HTH
3. Well use (check well use):	7d. Amount of disinfectant used: 1662.
Water Supply Well:	7e. Sealing materials used (check all that apply):
□Agricultural □Municipal/Public	□ Neat Cement Grout □ Bentonite Chips or Pellets
Geothermal (Heating/Cooling Supply) AResidential Water Supply (single)	Sand Cement Grout Dry Clay
□Industrial/Commercial □Residential Water Supply (shared)	☐ Concrete Grout ☐ Drill Cuttings
Non-Water Supply Well:	☐ Specialty Grout ☐ Gravel
□ Monitoring □ Recovery	☐ Bentonite Slurry ☐ Other (explain under 7g)
Injection Well:	7f. For each material selected above, provide amount of materials used:
□Aquifer Recharge □Groundwater Remediation	18my (101 10-31)
□Aquifer Storage and Recovery □Salinity Barrier	2 + Q 12 C + 2/1 ///
□Aquifer Test □Stormwater Drainage	- Dentark D-10 (EMENT 8 TO 9
□Experimental Technology □Subsidence Control □Geothermal (Closed Loop) □Tracer	7g. Provide a brief description of the abandonment procedure:
Geothermal (Heating/Cooling Return)	First with Chy
Could (explain under /g)	
4. Date well(s) abandoned: 10-4-19	
5a. Well location:	
Bate MAN Cuil Sorver lo	
E The Control of the	8. Certification: #2179
Facility/Owner Name  Facility ID# (if applicable)	d. ceranication:
Physical Address, City, and Zip	Mores W. Jackson 10-4-19
11 the state of 111	Signature of Certified Well Contractor or Well Owner Date
County Parcel Identification No. (PIN)	By signing this form, I hereby certify that the well(s) was (were) abandoned in
	accordance with 15A NCAC 02C .0100 or 2C .0200 Well Construction Standards and that a copy of this record has been provided to the well owner.
5b. Latitude and longitude in degrees/minutes/seconds or decimal degrees: (if well field, one lat/long is sufficient)	
35, 32, b N 78 5/35,3	9. Site diagram or additional well details: You may use the back of this page to provide additional well site details or well
W. Carrier and Car	abandonment details. You may also attach additional pages if necessary.
CONSTRUCTION DETAILS OF WELL(S) BEING ABANDONED  Attach well construction record(s) if available. For multiple injection or non-water supply	SUBMITTAL INSTRUCTIONS
wells ONLY with the same construction ahandonment, you can submit one form.	10a. For All Wells: Submit this form within 30 days of completion of well
6a. Well ID#:	abandonment to the following:
2.1	Division of Water Resources, Information Processing Unit,
6b. Total well depth:(ft.)	1617 Mail Service Center, Raleigh, NC 27699-1617
2.0	10b. For Injection Wells: In addition to sending the form to the address in 10a
6c. Borehole diameter: 22 (in.)	above, also submit one copy of this form within 30 days of completion of well
	abandonment to the following:
6d. Water level below ground surface:	Division of Water Resources, Underground Injection Control Program,
/ /	1636 Mail Service Center, Raleigh, NC 27699-1636
6c. Outer easing length (if known):(ft.)	10c. For Water Supply & Injection Wells: In addition to sending the form to the address(es) above, also submit one copy of this form within 30 days of
	completion of well abandonment to the county health department of the county
6f. Inner casing/tubing length (if known):(ft.)	where abandoned.
6. Samuel 1. 18 180	
6g. Screen length (if known):(ft.)	