

This form can be used for single or multiple wells

For Internal Use ONLY:

WELL ABANDONMENT DETAILS

1. Well Contractor Information:

Roger W. Jackson
Well Contractor Name (or well owner personally abandoning well on his/her property)
2179
NC Well Contractor Certification Number

JACKSON WELL Co
Company Name

2. Well Construction Permit #: EH 2001-0022
List all applicable well permits (i.e. County, State, Variance, Injection, etc.) if known

3. Well use (check well use):

Water Supply Well:
Agricultural
Geothermal (Heating/Cooling Supply)
Industrial/Commercial
Irrigation
Non-Water Supply Well:
Monitoring
Recovery
Injection Well:
Aquifer Recharge
Aquifer Storage and Recovery
Aquifer Test
Experimental Technology
Geothermal (Closed Loop)
Geothermal (Heating/Cooling Return)
Municipal/Public
Residential Water Supply (single)
Residential Water Supply (shared)
Groundwater Remediation
Salinity Barrier
Stormwater Drainage
Subsidence Control
Tracer
Other (explain under 7g)

7a. Number of wells being abandoned: 1
For multiple injection or non-water supply wells ONLY with the same construction/abandonment, you can submit one form.

7b. Approximate volume of water remaining in well(s): 40 (gal.)

FOR WATER SUPPLY WELLS ONLY:

7c. Type of disinfectant used: HTH

7d. Amount of disinfectant used: 16oz.

7e. Sealing materials used (check all that apply):

- Neat Cement Grout
Sand Cement Grout
Concrete Grout
Specialty Grout
Bentonite Slurry
Bentonite Chips or Pellets
Dry Clay
Drill Cuttings
Gravel
Other (explain under 7g)

7f. For each material selected above, provide amount of materials used:

CEMENT 1yd
Dry Clay 4yds
200 lbs Bentonite Chips

7g. Provide a brief description of the abandonment procedure:

Pump water out of well
add bentonite ch.
add CLAY
Concrete Top 6'

8. Certification: #2179
Roger W. Jackson
Signature of Certified Well Contractor or Well Owner
3-6-20
Date

By signing this form, I hereby certify that the well(s) was (were) abandoned in accordance with 15A NCAC 02C .0100 or 2C .0200 Well Construction Standards and that a copy of this record has been provided to the well owner.

9. Site diagram or additional well details:
You may use the back of this page to provide additional well site details or well abandonment details. You may also attach additional pages if necessary.

SUBMITTAL INSTRUCTIONS

10a. For All Wells: Submit this form within 30 days of completion of well abandonment to the following:

Division of Water Resources, Information Processing Unit,
1617 Mail Service Center, Raleigh, NC 27699-1617

10b. For Injection Wells: In addition to sending the form to the address in 10a above, also submit one copy of this form within 30 days of completion of well abandonment to the following:

Division of Water Resources, Underground Injection Control Program,
1636 Mail Service Center, Raleigh, NC 27699-1636

10c. For Water Supply & Injection Wells: In addition to sending the form to the address(es) above, also submit one copy of this form within 30 days of completion of well abandonment to the county health department of the county where abandoned.

4. Date well(s) abandoned: 3-5-20

5a. Well location:
Smithfield Co. 7186
Facility/Owner Name: 1616 McKay Town Pl. Cameron NC. 28353
Physical Address, City, and Zip: Harnett
County: EH 2001-0022
Parcel Identification No. (PIN)

5b. Latitude and longitude in degrees/minutes/seconds or decimal degrees:
35° 14.944' N 79° 09.334' W

CONSTRUCTION DETAILS OF WELL(S) BEING ABANDONED

Attach well construction record(s) if available. For multiple injection or non-water supply wells ONLY with the same construction/abandonment, you can submit one form.

6a. Well ID#: # 2

6b. Total well depth: 50 (ft.)

6c. Borehole diameter: 24 (in.)

6d. Water level below ground surface: 3 (ft.)

6e. Outer casing length (if known): 50 (ft.)

6f. Inner casing/tubing length (if known): 0 (ft.)

6g. Screen length (if known): 0 (ft.)