



**North Carolina State Laboratory of Public Health**  
*Environmental Sciences*  
**Microbiology**  
**Certificate of Analysis**

4312 District Drive  
 MSC 1918  
 Raleigh, NC 27699-1918  
 http://slph.ncpublichealth.com  
 Phone: 919-733-7308  
 Fax: 919-715-8611

**FINAL REPORT**

**Report to:** Brittany Adams

**Name of System:**

**HARNETT CO ENVIRONMENTAL HEALTH**  
 307 CORNELIUS HARNETT BLVD  
 Lillington, NC 27546

**Johnathan Bowman**  
 13050 Hwy 210  
 Bunnlevel, NC 28323

**EIN:** 566000306EH

**Delivery:** NC Courier

**Harnett County**

StarLiMS ID: **ES200630-0045**

Date Collected: 06/29/2020

Time Collected: 12:00

By: Brittany Adams

Date Received: 06/30/2020

Time Received: 07:50

By: Denise Richardson

Sample Source: Well water

Sampling Point: Building spigot

Sample Type:

GPS No.

Treatment:

Well Permit No.

Comment:

**Colilert Profile**

**Method: SM 9223B**

Analyte	Test Result	Unit	Conclusion	Date Tested
Total Coliform	Absent			06/30/2020
E. coli	Absent			06/30/2020

**Report Date:** 07/01/2020

**Reported By:** **KPLEMMONS**

**Explanations of Coliform Analysis:**

If coliform bacteria are **Absent**, the water is considered safe for drinking purpose. If coliform bacteria are **Present**, the water is considered unsafe for drinking purpose. Presence of *E. coli* (bacteria) generally indicates that the water has been contaminated with fecal material. It must be remembered that a water analysis refers only to the sample received and should not be regarded as a complete report on the water supply.

North Carolina Division of Public Health  
Occupational and Environmental Epidemiology Branch, Epidemiology Section  
BIOLOGICAL ANALYSIS REPORT

Private well water information and recommendations

County: Harnett Name: Schnedman Sample ID Number: \_\_\_\_\_  
Location: 13050 HWY 210 Bowman Reviewer B. Adams

Initial Sample  Confirmation Sample \_\_\_\_\_

BIOLOGICAL ANALYSIS RESULTS AND RECOMMENDATIONS FOR USES OF YOUR PRIVATE WELL WATER (These recommendations are based on biological analysis only.)

No coliform bacteria were found in your well water. Your water can be used for all purposes including drinking, cooking, washing dishes, bathing and showering.

\_\_\_\_\_ Total coliform bacteria were detected in your water sample. Total Coliform are a group of related bacteria that are (with few exceptions) not harmful to humans. A variety of bacteria, parasites, and viruses, known as pathogens, can potentially cause health problems if humans ingest them. EPA considers total coliforms a useful indicator of other pathogens for drinking water. Total coliforms are used to determine the adequacy of water treatment and the integrity of the distribution system

\_\_\_\_\_ It is recommended that your well water be re-tested to verify that the result is accurate.

\_\_\_\_\_ Fecal coliform bacteria were detected in the sample. **Do not use the water for drinking, cooking, washing dishes, bathing or showering.**

If the re-test shows contamination by bacteria contact your local health department for assistance. There may be a problem with the construction of the well, the groundwater source, or operation of the well. The well needs to be inspected by the local health department or a local well contractor to determine the problem with the well and to give guidance on how to correct the problem.

Your well water was tested for biological contaminants (total coliform and fecal coliform bacteria). The results were evaluated using the federal drinking water standards.

Drinking water may contain substances that can occur naturally in water or can be introduced into water from man-made sources. Total coliform bacteria are found in soil and fecal coliform bacteria are found in animal and human waste. Total coliform or fecal coliform bacteria in well water indicate that the well may have structural problems or that the well was not properly disinfected.

If you have been drinking the well water and are pregnant, nursing, have a child in the household under 5 years of age, or immunocompromised (such as an individual with AIDS, cancer, hepatitis, dialysis or surgical procedures) inform your physician of these results at your next visit.

If the contamination continues, you should investigate the possibility of drilling a new well or installing a point-of-entry disinfection unit which can use chlorine, ultraviolet light, or ozone.

For further information please contact your county health department or the Occupational and Environmental Epidemiology Branch at 919-707-5900.