WELL ABANDONMENT RECORD For Internal Use ONLY 1. Well Contractor Information: WELL ABANDONMENT DETAILS 1 13001 7a. For Geoprobe/DPT or Closed-Loop Geothermal Wells having the same Well Contractor Name (or well owner personally abandoning well on his/her property) well construction/depth, only 1 GW-30 is needed. Indicate TOTAL NUMBER of wells abandoned: 7b. Approximate volume of water remaining in well(s): Bool well FOR WATER SUPPLY WELLS ONLY: 7c. Type of disinfectant used: Colcium Hyphochloute 2. Well Construction Permit #: 10 Octal was List all applicable well construction permits (i.e. UIC, County, State, 7d. Amount of disinfectant used: 3. Well use (check well use): Water Supply Well: 7e. Sealing materials used (check all that apply): □ Agricultural ☐Municipal/Public ☐ Neat Cement Grout ☐ Bentonite Chips or Pellets Desidential Water Supply (single) ☐ Geothermal (Heating/Cooling Supply) ☐ Sand Cement Grout ☐ Dry Clay □ Industrial/Commercial □ Residential Water Supply (shared) Concrete Grout ☐ Drill Cuttings □Irrigation ☐ Specialty Grout Non-Water Supply Well: ☐ Bentonite Slurry ☐ Other (explain under 7g) □Monitoring □ Recovery Injection Well: 7f. For each material selected above, provide amount of materials used: ☐ Aquifer Recharge ☐Groundwater Remediation ☐ Aquifer Storage and Recovery ☐Salinity Barrier □ Aquifer Test ☐Stormwater Drainage □Experimental Technology ☐Subsidence Control 7g. Provide a brief description of the abandonment procedure: ☐Geothermal (Closed Loop) □Tracer ☐Geothermal (Heating/Cooling Return) □Other (explain under 7g) 4. Date well(s) abandoned: 1/12/2 4 5a. Well location: Bradley Butt - INC Facility ID# (if applicable) 8. Certification: Piney Grove By signing this form, I hereby certify that the well(s) was (were) abandoned in accordance with 15A NCAC 02C .0100 or 2C .0200 Well Construction Standards and that a copy of this record has been provided to the well owner. 5b. Latitude and longitude in degrees/minutes/seconds or decimal degrees: (if well field, one lat/long is sufficient) 9. Site diagram or additional well details: You may use the back of this page to provide additional well site details or well 5.500799 N -78.683399 abandonment details. You may also attach additional pages if necessary. CONSTRUCTION DETAILS OF WELL(S) BEING ABANDONED SUBMITTAL INSTRUCTIONS Attach well construction record(s) if available. For multiple injection or non-water supply wells ONLY with the same construction/abandonment, you can submit one form. 10a. For All Wells: Submit this form within 30 days of completion of well abandonment to the following: 6a. Well ID#: Division of Water Resources, Information Processing Unit, 1617 Mail Service Center, Raleigh, NC 27699-1617 6b. Total well depth: 10b. For Injection Wells: In addition to sending the form to the address in 10a above, also submit one copy of this form within 30 days of completion of well 6c. Borehole diameter: abandonment to the following: Division of Water Resources, Underground Injection Control Program, 6d. Water level below ground surface: 1636 Mail Service Center, Raleigh, NC 27699-1636 10c. For Water Supply & Injection Wells: In addition to sending the form to the 6e. Outer casing length (if known): address(es) above, also submit one copy of this form within 30 days of completion of well abandonment to the county health department of the county where

6f. Inner casing/tubing length (if known):

6g. Screen length (if known):

abandoned