WELL ABANDONMENT RECORD For Internal Use ONLY: 1. Well Contractor Information: WELL ABANDONMENT DETAILS 7a. For Geoprobe/DPT or Closed-Loop Geothermal Wells having the same well construction/depth, only 1 GW-30 is needed. Indicate TOTAL NUMBER of NC Well Contractor Certification Number 7b. Approximate volume of water remaining in well(s): _ Building G. I (gal.) FOR WATER SUPPLY WELLS ONLY: 2. Well Construction Permit #: List all applicable well construction permits (i.e. UIC, County, State, Variance, etc.) if know 7c. Type of disinfectant used: _____ Bleach 7d. Amount of disinfectant used: ___ Gallon -3. Well use (check well use): Water Supply Well: 7e. Sealing materials used (check all that apply): ☐ Agricultural ☐Municipal/Public ☐ Neat Cement Grout ☐Geothermal (Heating/Cooling Supply) ☐ Bentonite Chips or Pellets Residential Water Supply (single) ☐ Sand Cement Grout ☐ Dry Clay □Industrial/Commercial □Residential Water Supply (shared) Concrete Grout ☐ Drill Cuttings □ Irrigation ☐ Specialty Grout Non-Water Supply Well: ☐ Gravel ☐ Bentonite Slurry ☐ Monitoring ☐ Other (explain under 7g) □ Recovery Injection Well: 7f. For each material selected above, provide amount of materials used: □Aquifer Recharge ☐Groundwater Remediation approx 2.8 yards □Aquifer Storage and Recovery ☐Salinity Barrier □Aquifer Test ☐Stormwater Drainage □Experimental Technology ☐Subsidence Control 7g. Provide a brief description of the abandonment procedure: ☐Geothermal (Closed Loop) ☐Tracer ☐Geothermal (Heating/Cooling Return) □Other (explain under 7g) Der. 6 2024 4. Date well(s) abandoned: 5a. Well location: Facility ID# (if applicable) 8. Certification: Signature of Certified Well Contrag By signing this form, I hereby certify that the well(s) was (were) abandoned in County Parcel Identification No. (PIN) accordance with 15A NCAC 02C .0100 or 2C .0200 Well Construction Standards and that a copy of this record has been provided to the well owner. 5b. Latitude and longitude in degrees/minutes/seconds or decimal degrees: (if well field, one lat/long is sufficient) 9. Site diagram or additional well details: 35.50 7204 1428 9342 You may use the back of this page to provide additional well site details or well abandonment details. You may also attach additional pages if necessary. CONSTRUCTION DETAILS OF WELL(S) BEING ABANDONED SUBMITTAL INSTRUCTIONS Attach well construction record(s) if available. For multiple injection or non-water supply wells ONLY with the same construction/abandonment, you can submit one form. 10a. For All Wells: Submit this form within 30 days of completion of well 6a. Well ID#: Unknown abandonment to the following: Division of Water Resources, Information Processing Unit, 6b. Total well depth: 1617 Mail Service Center, Raleigh, NC 27699-1617 10b. For Injection Wells: In addition to sending the form to the address in 10a 6c. Borehole diameter: above, also submit one copy of this form within 30 days of completion of well abandonment to the following: 6d. Water level below ground surface: UN Known (ft.)

Division of Water Resources, Underground Injection Control Program, 1636 Mail Service Center, Raleigh, NC 27699-1636

10c. For Water Supply & Injection Wells: In addition to sending the form to the address(es) above, also submit one copy of this form within 30 days of completion of well abandonment to the county health department of the county where abandoned.

6e. Outer casing length (if known): _____ / 8 💍

6f. Inner casing/tubing length (if known):

6g. Screen length (if known):

UNKrown (ft)