## WELL ABANDONMENT RECORD For Internal Use ONLY: 1. Well Contractor Information: WELL ABANDONMENT DETAILS Andrew Price 7a. For Geoprobe/DPT or Closed-Loop Geothermal Wells having the same well construction/depth, only 1 GW-30 is needed. Indicate TOTAL NUMBER of Well Contractor Name (or well owner personally abandoning well on his/her property) 4714-C 7b. Approximate volume of water remaining in well(s): 32 NC Well Contractor Certification Number Charles R. Underwood Inc. FOR WATER SUPPLY WELLS ONLY: Company Name 7c. Type of disinfectant used: HTH 2. Well Construction Permit #: EH2411-0007 List all applicable well construction permits (i.e. UIC, County, State, Variance, etc.) if known 7d. Amount of disinfectant used: 30Z 3. Well use (check well use): Water Supply Well: 7e. Sealing materials used (check all that apply): □Agricultural ☐Municipal/Public ■ Neat Cement Grout ☐ Bentonite Chips or Pellets ■Residential Water Supply (single) ☐ Sand Cement Grout ☐ Dry Clay ☐ Geothermal (Heating/Cooling Supply) □ Industrial/Commercial □Residential Water Supply (shared) ☐ Concrete Grout □ Drill Cuttings □Irrigation ☐ Specialty Grout ☐ Gravel Non-Water Supply Well: ☐ Bentonite Slurry ☐ Other (explain under 7g) □Monitoring □Recovery 7f. For each material selected above, provide amount of materials used: Injection Well: ☐ Aquifer Recharge ☐Groundwater Remediation Neat Cement 4 yards ☐ Aquifer Storage and Recovery □Salinity Barrier □ Aquifer Test □Stormwater Drainage □Experimental Technology ☐Subsidence Control 7g. Provide a brief description of the abandonment procedure: ☐Geothermal (Closed Loop) □Tracer Removed top 3-feet of well tile, pumped all the remaining water out of the well ☐Geothermal (Heating/Cooling Return) □Other (explain under 7g) and filled to the top with cement grout including the surrounding excavation 4. Date well(s) abandoned: 1/31/25 around the removed tiles. 5a. Well location: Harnett County Parks & Recreation 8. Certification: Facility ID# (if applicable) Facility/Owner Name Andrew Price 254 American Legion Rd, Bunnlevel, NC 28323 2/3/25 Physical Address, City, and Zip Signature of Certified Well Contractor or Well Owner Harnett By signing this form, I hereby certify that the well(s) was (were) abandoned in Parcel Identification No. (PIN) accordance with 15A NCAC 02C .0100 or 2C .0200 Well Construction Standards and that a copy of this record has been provided to the well owner. 5b. Latitude and longitude in degrees/minutes/seconds or decimal degrees: (if well field, one lat/long is sufficient) 9. Site diagram or additional well details: 35.361651 -78.839464 You may use the back of this page to provide additional well site details or well abandonment details. You may also attach additional pages if necessary. CONSTRUCTION DETAILS OF WELL(S) BEING ABANDONED SUBMITTAL INSTRUCTIONS Attach well construction record(s) if available. For multiple injection or non-water supply wells ONLY with the same construction/abandonment, you can submit one form. 10a. For All Wells: Submit this form within 30 days of completion of well abandonment to the following: 6a. Well ID#: Division of Water Resources, Information Processing Unit, 6b. Total well depth: 10 1617 Mail Service Center, Raleigh, NC 27699-1617 10b. For Injection Wells: In addition to sending the form to the address in 10a 6c. Borehole diameter: 28 above, also submit one copy of this form within 30 days of completion of well abandonment to the following: 6d. Water level below ground surface: 9 Division of Water Resources, Underground Injection Control Program, 1636 Mail Service Center, Raleigh, NC 27699-1636 10c. For Water Supply & Injection Wells: In addition to sending the form to the 6e. Outer casing length (if known): \_\_\_\_\_\_(ft.) address(es) above, also submit one copy of this form within 30 days of completion of well abandonment to the county health department of the county where abandoned. 6f. Inner casing/tubing length (if known): \_\_\_\_\_(ft.)

6g. Screen length (if known): \_\_\_