WELL ABANDONMENT RECORD	For Internal Use ONLY:
1. Well Contractor Information:	WELL ABANDONMENT DETAILS
Well Contractor Name (or well owner personally abandoning well on his/her property)	7a. For Geoprobe/DPT or Closed-Loop Geothermal Wells having the same well construction/depth, only 1 GW-30 is needed. Indicate TOTAL NUMBER of
	wells abandoned:
NC Well Contractor Certification Number	7b. Approximate volume of water remaining in well(s):(gal.
Beal well & Pump	FOR WATER SUPPLY WELLS ONLY:
Company Name	7c. Type of disinfectant used: Colcium Hypochlonita
2. Well Construction Permit #: EH 2411 - 00/6 List all applicable well construction permits (i.e. UIC, County, State, Variance, etc.) if know	
3. Well use (check well use):	7d. Amount of disinfectant used:
Water Supply Well:	7e. Sealing materials used (check all that apply):
□ Agricultural □ Municipal/Public	☑ Neat Cement Grout ☐ Bentonite Chips or Pellets
Geothermal (Heating/Cooling Supply)	☐ Sand Cement Grout ☐ Dry Clay
□Industrial/Commercial □Residential Water Supply (shared) Concrete Grout Drill Cuttings
□Irrigation	☐ Specialty Grout ☐ Gravel
Non-Water Supply Well:	Bentonite Slurry Other (explain under 7g)
□Monitoring □Recovery Injection Well:	76 For each material selected shows associate amount of materials and
□Aquifer Recharge □Groundwater Remediation	7f. For each material selected above, provide amount of materials used:
□ Aquifer Storage and Recovery □ Salinity Barrier	Bertonite Good & Coment
□ Aquifer Test □Stormwater Drainage	
□Experimental Technology □Subsidence Control	
□Geothermal (Closed Loop) □Tracer	7g. Provide a brief description of the abandonment procedure:
□Geothermal (Heating/Cooling Return) □Other (explain under 7g)	Dug Down & Cut cosing
4. Date well(s) abandoned: 12/17/24 5a. Well location:	Cener
Torheel Restoration INC	
racinty/Owner Name Pacinty ID# (II applicable)	8. Certification:
188 Shody Book Ly Fuguay	12/17/24
Physical Address, City, and Zip	Separatire of Certified Well Contractor or Well Owner Date
County Parcel Identification No. (PIN)	 By signing this form, I hereby certify that the well(s) was (were) abandoned is accordance with 15A NCAC 02C .0100 or 2C .0200 Well Construction Standard
5b. Latitude and longitude in degrees/minutes/seconds or decimal degrees:	and that a copy of this record has been provided to the well owner.
(if well field, one lat/long is sufficient)	9. Site diagram or additional well details:
35.50675 N 78.80216	You may use the back of this page to provide additional well site details or we abandonment details. You may also attach additional pages if necessary.
CONSTRUCTION DETAILS OF WELL(S) BEING ABANDONED Attach well construction record(s) if available. For multiple injection or non-water supply we	Ils SUBMITTAL INSTRUCTIONS
ONLY with the same construction/abandonment, you can submit one form. 6a. Well ID#:	10a. For All Wells: Submit this form within 30 days of completion of well abandonment to the following:
6b. Total well depth:(ft.)	Division of Water Resources, Information Processing Unit, 1617 Mail Service Center, Raleigh, NC 27699-1617
6c. Borehole diameter:	10b. For Injection Wells: In addition to sending the form to the address in 10 above, also submit one copy of this form within 30 days of completion of we abandonment to the following:
6d. Water level below ground surface:(ft.)	Division of Water Resources, Underground Injection Control Program, 1636 Mail Service Center, Raleigh, NC 27699-1636
6e. Outer casing length (if known):(ft.) 6f. Inner casing/tubing length (if known):(ft.)	10c. For Water Supply & Injection Wells: In addition to sending the form to the address(es) above, also submit one copy of this form within 30 days of completio of well abandonment to the county health department of the county when abandoned.
6f. Inner casing/tubing length (if known): //// (ft.)	
6g. Screen length (if known):(ft.)	