WELL ABANDONMENT RECORD		For Internal Use ONLY:	
1. Well Contractor Information:		WELL ABANDONMENT DETAILS	
,			
Well Contractor Name (or well owner personally abandoning well on his/her property)		7a. For Geoprobe/DPT or Closed-Loop Geothermal Wells having the same well construction/depth, only 1 GW-30 is needed. Indicate TOTAL NUMBER of	
	abandoning wen on his/her property)	wells abandoned:	
NC Well Contractor Certification Number		7b. Approximate volume of water remaining in well(s):	1,102 (gal.
2			
Company Name		FOR WATER SUPPLY WELLS ONLY:	
A .	<i>i</i>	7c. Type of disinfectant used: Colour 1+4po	ryloute.
2. Well Construction Permit #:		1/	-
		7d. Amount of disinfectant used:	
3. Well use (check well use):		1	
Water Supply Well:	=V-:	7e. Sealing materials used (check all that apply):	CI. D.II.
□ Agricultural	□Manicipal/Public	5 20 CO	Chips or Pellets
Geothermal (Heating/Cooling Supply)	Residential Water Supply (single)	☐ Sand Cement Grout ☐ Dry Clay	
□Industrial/Commercial	□Residential Water Supply (shared)	□ Concrete Grout □ Drill Cuttin	ngs
□Irrigation Non-Water Supply Well:		☐ Specialty Grout ☐ Gravel	
Monitoring   Monitoring	□Recovery	☐ Bentonite Slurry ☐ Other (exp	plain under 7g)
Injection Well:	ERECOVERY	7f. For each material selected above, provide amount of	f materials used:
□ Aquifer Recharge	☐Groundwater Remediation		nest-
☐ Aquifer Storage and Recovery	□Salinity Barrier	Bentonite plus CCI	177
□Aquifer Test	□Stormwater Drainage	Clean Grovel	
□Experimental Technology	□Subsidence Control		
□Geothermal (Closed Loop)	□Tracer	7g. Provide a brief description of the abandonment pro	
☐Geothermal (Heating/Cooling Return)	□Other (explain under 7g)	Dig Down & Removed 4 fe	et of cemu
		Cosins filled with Groval	A Bentonite.
4. Date well(s) abandoned: 3/12/25			
		Secled top with cener	F'.
5a. Well location:		Covered with executed	12:6
RLT Construction			
Facility/Owner Name	Facility ID# (if applicable)	8. Certification:	
602 wondertown DR, ERWIN, NC			3/12/23
Physical Address, City, and Zip		Signature of Certified Well Contractor or Well Owner	Date
Hospitt		Design the Complete that the self-state will be	
County	Parcel Identification No. (PIN)	By signing this form, I hereby certify that the well(s) we accordance with 15A NCAC 02C .0100 or 2C .0200 Well	
5h Latitude and longitude in degrees/po	inutes (see souds on desired) despesse	and that a copy of this record has been provided to the well	
5b. Latitude and longitude in degrees/minutes/seconds or decimal degrees: (if well field, one lat/long is sufficient)		9. Site diagram or additional well details: You may use the back of this page to provide additional well site details or well abandonment details. You may also attach additional pages if necessary.	
35.31993 N -78.65130 W			
CONSTRUCTION DETAILS OF WELL(S) BEING ABANDONED  Attach well construction record(s) if available. For multiple injection or non-water supply wells		SUBMITTAL INSTRUCTIONS	
ONLY with the same construction/abandonment, 6a. Well ID#:	, you can submit one form.	10a. For All Wells: Submit this form within 30 days abandonment to the following:	of completion of well
6b. Total well depth: 59	(ft.)	Division of Water Resources, Information Pro 1617 Mail Service Center, Raleigh, NC 27	
ob. Total well depth:	_(ii.)		
6c. Borehole diameter: 24 (in.)		10b. For Injection Wells: In addition to sending the form to the address in 10a above, also submit one copy of this form within 30 days of completion of well abandonment to the following:	
6d. Water level below ground surface: _	/O(ft.)	Division of Water Resources, Underground Injection Control Program, 1636 Mail Service Center, Raleigh, NC 27699-1636	
6e. Outer casing length (if known):(ft.)		10c. For Water Supply & Injection Wells: In addition to sending the form to the address(es) above, also submit one copy of this form within 30 days of completion of well abandonment to the county health department of the county where abandoned.	
6f. Inner casing/tubing length (if known	):(ft.)	nominity).	
6g. Screen length (if known):	$M/A^{c}$ (ft.)		