

WELL ABANDONMENT RECORD

1. Well Contractor Information:

James Sealey

Well Contractor Name (or well owner personally abandoning well on his/her property)

4675-A

NC Well Contractor Certification Number

Sealey Well Drilling LLC

Company Name

2. Well Construction Permit #:

EH2504-0017

List all applicable well construction permits (i.e. UIC, County, State, Variance, etc.) if known

3. Well use (check well use):

Water Supply Well:

- | | |
|--|--|
| ☐ Agricultural | ☐ Municipal/Public |
| ☐ Geothermal (Heating/Cooling Supply) | ☐ Residential Water Supply (single) |
| ☐ Industrial/Commercial | ☐ Residential Water Supply (shared) |
| ☐ Irrigation | |

Non-Water Supply Well:

- | | |
|-------------------------------------|-----------------------------------|
| ☐ Monitoring | ☐ Recovery |
|-------------------------------------|-----------------------------------|

Injection Well:

- | | |
|--|---|
| ☐ Aquifer Recharge | ☐ Groundwater Remediation |
| ☐ Aquifer Storage and Recovery | ☐ Salinity Barrier |
| ☐ Aquifer Test | ☐ Stormwater Drainage |
| ☐ Experimental Technology | ☐ Subsidence Control |
| ☐ Geothermal (Closed Loop) | ☐ Tracer |
| ☐ Geothermal (Heating/Cooling Return) | ☐ Other (explain under 7g) |

4. Date well(s) abandoned: 6-18-25

5a. Well location:

White Oak Homes

Facility/Owner Name

Facility ID# (if applicable)

3180 Cameron Hill Rd

Physical Address, City, and Zip

Harnett

County

Parcel Identification No. (PIN)

5b. Latitude and longitude in degrees/minutes/seconds or decimal degrees:

(if well field, one lat/long is sufficient)

_____ N _____ W

CONSTRUCTION DETAILS OF WELL(S) BEING ABANDONED

Attach well construction record(s) if available. For multiple injection or non-water supply wells ONLY with the same construction abandonment, you can submit one form.

6a. Well ID#: _____

6b. Total well depth: 81 (ft.)

6c. Borehole diameter: _____ (in.)

6d. Water level below ground surface: 60 (ft.)

6e. Outer casing length (if known): _____ (ft.)

6f. Inner casing/tubing length (if known): _____ (ft.)

6g. Screen length (if known): _____ (ft.)

For Internal Use ONLY:

WELL ABANDONMENT DETAILS

7a. For Geoprobe/DPT or Closed-Loop Geothermal Wells having the same well construction/depth, only 1 GW-30 is needed. Indicate TOTAL NUMBER of wells abandoned: _____

7b. Approximate volume of water remaining in well(s): 493 (gal.)

FOR WATER SUPPLY WELLS ONLY:

7c. Type of disinfectant used: granulated chlorine

7d. Amount of disinfectant used: 15 oz

7e. Sealing materials used (check all that apply):

- | | |
|--|---|
| ☐ Neat Cement Grout | ☐ Bentonite Chips or Pellets |
| ☐ Sand Cement Grout | ☒ Dry Clay |
| ☐ Concrete Grout | ☐ Drill Cuttings |
| ☐ Specialty Grout | ☐ Gravel |
| ☐ Bentonite Slurry | ☐ Other (explain under 7g) |

7f. For each material selected above, provide amount of materials used:

5.5 yds

7g. Provide a brief description of the abandonment procedure:

Chlorinate well, pump water out of well, remove as much concrete tile at least 3ft, backfill with sand/clay, pour concrete cap on top of well casing, backfill the rest with sand/clay

8. Certification:

Jim Sealey

Signature of Certified Well Contractor or Well Owner

6-18-25

Date

By signing this form, I hereby certify that the well(s) was (were) abandoned in accordance with 15A NCAC 02C .0100 or 2C .0200 Well Construction Standards and that a copy of this record has been provided to the well owner.

9. Site diagram or additional well details:

You may use the back of this page to provide additional well site details or well abandonment details. You may also attach additional pages if necessary.

SUBMITTAL INSTRUCTIONS

10a. **For All Wells:** Submit this form within 30 days of completion of well abandonment to the following:

Division of Water Resources, Information Processing Unit,
1617 Mail Service Center, Raleigh, NC 27699-1617

10b. **For Injection Wells:** In addition to sending the form to the address in 10a above, also submit one copy of this form within 30 days of completion of well abandonment to the following:

Division of Water Resources, Underground Injection Control Program,
1636 Mail Service Center, Raleigh, NC 27699-1636

10c. **For Water Supply & Injection Wells:** In addition to sending the form to the address(es) above, also submit one copy of this form within 30 days of completion of well abandonment to the county health department of the county where abandoned.