## WELL ARANDONMENT RECORD

WEEL MAINDONWENT RECORD	For Internal Use ONLY:
1. Well Contractor Information:	WELL ABANDONMENT DETAILS
James Sealey	T. F. C. I (DDT) CI IV
Well Contractor Name (or well owner personally abandoning well on his/her property)	7a. For Geoprobe/DPT or Closed-Loop Geothermal Wells having the same well construction/depth, only 1 GW-30 is needed. Indicate TOTAL NUMBER of
4675-A	wells abandoned:
NC Well Contractor Certification Number	7b. Approximate volume of water remaining in well(s): 493 (gal.)
Sealey Well Drilling LLC	
Company Name	FOR WATER SUPPLY WELLS ONLY:
EII DEALL DOLL	7c. Type of disinfectant used: Ofanulated Chroire
2. Well Construction Permit #: L T + O H - O L List all applicable well construction permits (i.e. UIC, County, State, Variance, etc.) if known	15
	7d. Amount of disinfectant used:
3. Well use (check well use):	
Water Supply Well:  □Agricultural □Municipal/Public	7e. Sealing materials used (check all that apply):
□ Agricultural □ Municipal/Public □ Geothermal (Heating/Cooling Supply) □ Residential Water Supply (single)	□ Neat Cement Grout □ Bentonite Chips or Pellets
□ Industrial/Commercial □ Residential Water Supply (shared)	□ Sand Cement Grout □ Concrete Grout □ Drill Cuttings
□Irrigation	☐ Concrete Grout ☐ Drill Cuttings ☐ Specialty Grout ☐ Gravel
Non-Water Supply Well:	☐ Bentonite Slurry ☐ Other (explain under 7g)
□ Monitoring □ Recovery	y = outst (supram under /g)
Injection Well:  □Aquifer Recharge □Groundwater Remediation	7f. For each material selected above, provide amount of materials used:
	5.5 Vds
□ Experimental Technology □ Subsidence Control	
□Geothermal (Closed Loop) □Tracer	7g. Provide a brief description of the abandonment procedure:
☐Geothermal (Heating/Cooling Return) ☐Other (explain under 7g)	Chlorinate well sums mater out of
4. Date well(s) abandoned: 6-18-25	well, remove as much concrete tile at least 3ft, backfill with sandclay.
5a. Well location: White Oak Homes	pour concrete cap on top of well casing,
Facility/Owner Name Facility ID# (if applicable)	8. certification! The rest with sand clay
3180 Cameron Hill Rd	00/800/pV (-14-)=
Physical Address, City, and Zip	Signature of Certified Well Contractor or Well Owner Date
Harnett	By signing this form. I hereby certify that the well(s) was (were) abandoned in
County Parcel Identification No. (PIN)	accordance with 15A NCAC 02C .0100 or 2C .0200 Well Construction Standards
5b. Latitude and longitude in degrees/minutes/seconds or decimal degrees:	and that a copy of this record has been provided to the well owner.
(if well field, one lat/long is sufficient)	9. Site diagram or additional well details:
N	You may use the back of this page to provide additional well site details or well abandonment details. You may also attach additional pages if necessary.
CONSTRUCTION DETAILS OF WELL(S) BEING ABANDONED  Attach well construction record(s) if available. For multiple injection or non-water supply wells	SUBMITTAL INSTRUCTIONS
ONLY with the same construction abandonment, you can submit one form.	10a. For All Wells: Submit this form within 30 days of completion of well
6a. Well ID#:	abandonment to the following:
6b. Total well depth:(ft.)	Division of Water Resources, Information Processing Unit, 1617 Mail Service Center, Raleigh, NC 27699-1617
6c. Borehole diameter:(in.)	<b>10b.</b> For Injection Wells: In addition to sending the form to the address in 10a above, also submit one copy of this form within 30 days of completion of well abandonment to the following:
6d. Water level below ground surface:(ft.)	Division of Water Resources, Underground Injection Control Program, 1636 Mail Service Center, Raleigh, NC 27699-1636
6e. Outer casing length (if known):(ft.)	10c. For Water Supply & Injection Wells: In addition to sending the form to the
6f. Inner casing/tubing length (if known):(ft.)	address(es) above, also submit one copy of this form within 30 days of completion of well abandonment to the county health department of the county where abandoned.
6g. Screen length (if known):(ft.)	