WELL ABANDONMENT RECORD	For Internal Use ONLY:
1. Well Contractor Information:	WELL ABANDONMENT DETAILS
James Sealey	7n. For Geoprobe/DPT or Closed-Loop Geothermal Wells having the same
Well Contractor Name (or well owner personally abandoning well on his/her property) 4675-A	well construction/depth, only I GW-30 is needed Indicate TOTAL NUMBER 4 wells abandoned
NC Well Contractor Certification Number	7b. Approximate volume of water remaining in well(s):(ga
Sealey Well Drilling LLC	FOR WATER SUPPLY WELLS ONLY:
Company Name	- 1 1 1 1 1
2. Well Construction Permit #: EH 2507-0017	7c. Type of disinfectant used: <u>granulated</u> (hlorine
List all applicable well construction permits (i.e. UIC, County, State, Variance, etc.) if known	7d. Amount of disinfectant used: 402
3. Well use (check well use);	
Water Supply Well:	7e. Sealing materials used (check all that apply):
□Agricultural □Municipal/Public	□ Neat Cement Grout
Geothermal (Heating/Cooling Supply) Residential Water Supply (single)	☐ Sand Cement Grout ☐ Dry Clay
□Industrial/Commercial □Residential Water Supply (shared)	☐ Concrete Grout ☐ Drill Cuttings
□lrrigation	☐ Specialty Grout
Non-Water Supply Well:	☐ Bentonite Slurry ☐ Other (explain under 7g)
□Monitoring □Recovery Injection Well:	⅃ ͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺͺ
	7f. For each material selected above, provide amount of materials used:
The second secon	I vard of aravel
leave of many	The of the star
□ Experimental Technology □ Subsidence Control	- bags of hole play
□ Geothermal (Closed Loop) □ Tracer	7g. Provide a brief description of the abandonment procedure:
Geothermal (Heating/Cooling Return) Other (explain under 7g)	Measure Static & total depth of well.
4. Date well(s) abandoned: 9-22-25 5a. Well location:	Chlorinate well, add grovel, then from 36ft up with bentonite chips
Sandhills Real Estate Facility/Owner Name Facility/Owner Name Facility ID# (if analyzable)	8. Certification:
1/35 Usl C 01	8. Certification:
1635 Hilmon Grove Rd	- Dim/ Dlacky 9-22-25
Physical Address, City, and Zip	Signature of Certified Well Contractor or Well Owner Date
<u>Harnett</u>	By signing this form, I hereby certify that the well(s) was (were) abandoned in
County Parcel Identification No. (PIN)	accordance with 15A NCAC 02C .0100 or 2C .0200 Well Construction Standards
5b. Latitude and longitude in degrees/minutes/seconds or decimal degrees:	and that a copy of this record has been provided to the well owner.
(if well field, one lat/long is sufficient)	9. Site diagram or additional well details:
	You may use the back of this page to provide additional well site details or well abandonment details. You may also attach additional pages if necessary.
CONSTRUCTION DETAILS OF WELL(S) BEING ABANDONED	CUDMITTAL INCTDUCTIONS
Attach well construction record(s) if available. For multiple injection or non-water supply well ONLY with the same construction abandonment, you can submit one form.	
	10a. For All Wells: Submit this form within 30 days of completion of well abandonment to the following:
6a. Well ID#:	
6b. Total well depth:(ft.)	Division of Water Resources, Information Processing Unit, 1617 Mail Service Center, Raleigh, NC 27699-1617
6c. Borehole diameter:(in.)	10b. For Injection Wells: In addition to sending the form to the address in 10a above, also submit one copy of this form within 30 days of completion of well abandonment to the following
6d. Water level below ground surface:	Division of Water Resources, Underground Injection Control Program, 1636 Mail Service Center, Raleigh, NC 27699-1636
6e. Outer casing length (if known):(ft.)	10c. For Water Supply & Injection Wells: In addition to sending the form to the address(es) above, also submit one copy of this form within 30 days of completion of well abandonment to the county health department of the county where
6f. Inner casing/tubing length (if known):(ft.)	abandoned to the county health department of the county where

6g. Screen length (if known): _

____(ft.)