

Down Force

Mounting Plane	1		2		3		4		5	
Module Location	EM	IM	EM	IM	EM	IM	EM	IM	EM	IM
D+S (psf)	10.72	10.72								
D+06W (psf)	11.07	8.30								

Mounting Plane	6		7		8		9		10	
Module Location	EM	IM	EM	IM	EM	IM	EM	IM	EM	IM
D+S (psf)										
D+06W (psf)										

Lateral Parallel to Roof

Mounting Plane	1	2	3	4	5
D+S (psf)	4.33				

Mounting Plane	6	7	8	9	10
D+S (psf)					

Framing Check

Lumber Species: DF

PV Load = 3 psf

Mounting Plane	1	2	3	4	5
Framing Type	Truss				
Framing Size	2x6				
Framing Spacing (in)	24				
Span (ft)	7				
Moment (lb-ft)	217				
Shear (lbs)	124				
% Stressed	22%				
Upgrade Size	NA				
New % Stressed	NA				

Mounting Plane	6	7	8	9	10
Framing Type					
Framing Size					
Framing Spacing (in)					
Span (ft)					
Moment (lb-ft)					
Shear (lbs)					
% Stressed					
Upgrade Size					
New % Stressed					



Array Attachment Spacing

Module = HANWHA QCELL: Q.PEAK DUO BLK ML-G10+ 410

Mounting Plane	1	2	3	4	5
Roofing Material	Comp Shingle				
Attachment Type	Ecofasten RockIt Smart Slide				
Lag Count Per Attachment	2				
Min Lag Embedment (in)	2				
Landscape	72				
Portrait	48				

Mounting Plane	6	7	8	9	10
Roofing Material					
Attachment Type					
Lag Count Per Attachment					
Min Lag Embedment (in)					
Landscape					
Portrait					