

WARNING! Long span trusses, 60' or greater in length, require extreme care and experience for proper and safe handling and installation. For general handling and installation guidance, see the "Guide to Good Practice for Handling, Installing, Restraining Metal Plate Connected Wood Trusses ("BCSI"), JOINTLY PRODUCED BY SBCA and TPI. For project specific guidance, consult with a registered design professional. ATLANTIC assumes no responsibility for the handling, installation or bracing of trusses.

Ø

Bracing of

50	ATTIC TRUSS ABOVE		19-
	NOTE PLUMBING DROPS: PLUMBING SYMBOLS SHOWN ARE APPROXIMATE LOCATIONS ONLY. TRUSSES HAVE ALREADY BEEN SHIFTED WHERE NEEDED. BUILDER TO FIELD VERIFY ACTUAL LOCATIONS TO AVOID POSSIBLE CONFLICTS WITH TRUSSES. CLEAR DISTANCE FOR FLOOR DECKING NOT TO EXCEED 24". ***FLOOR TRUSSES ARE NOT TO BE DRILLED OR CUT IN ANY WAY ***		
	23-08-00	10-00-00	
	33-08-00		

▲= LEFT END OF TRUSS

NOT FOR CONSTRUCTION

	Job: Plan Infor	CAPITOL CI LOT 1157 CA mation: (LAUS-EURC	RRIAG	•	FLOOR
Moncks Corner/Easley, SC (800) 475-3999	NOT TO Drawn B		Date: / / Job #: 21-1988-F02	Sales Rep: KYLE GIBSON Phone:	