



4. Follow TP1 Requirements for Long Span Trusses (>60').

Never Underestimate the Power of Being First