


Products					
PlotID	Length	Product	Plies	Net Qty	Fab Type
1	30' 0"	16" TJI® 210	1	7	MFD
2	20' 0"	16" TJI® 210	1	18	MFD
3	14' 0"	16" TJI® 210	1	1	MFD
4	12' 0"	16" TJI® 210	1	1	MFD
5	10' 0"	16" TJI® 210	1	11	MFD
6	4' 0"	16" TJI® 210	1	1	FF
6	4' 0"	16" TJI® 210	1	1	MFD
7	2' 0"	16" TJI® 210	1	2	MFD
8	16' 0"	1 1/8" x 16" TJ® Rim Board	1	9	MFD
Bk1	2' 0"	16" TJI® 210	1	9	MFD
FB1	20' 0"	1 3/4" x 16" 2.0E Microllam® LVL	3	3	MFD
FB2	14' 0"	1 3/4" x 16" 2.0E Microllam® LVL	2	2	MFD
FB3	22' 0"	1 3/4" x 18" 2.0E Microllam® LVL	4	4	MFD

Connector Summary				
PlotID	Qty	Manuf	Product	Flange
H1	1	Simpson	HGUS414	None
H2	37	Simpson	IUS2.06/16	None
6 3/4" Screws*	60		*	None

Fasten Plies w/ 2 Rows of Screws 16" O.C.

2F - 2nd Floor I-Joist Layout

Elevation A

 Indicates "NO CUT END" === Material to be Trimmed from OTHER END ONLY		<p style="text-align: center;">*** ANY Concealed Flange Hangers MUST be Installed PRIOR to Setting the Carried Members!! ***</p>	
International Residential Code - R502.8.2 Engineered Wood Products - - - Cuts, notches and holes bored in trusses, laminated veneer lumber, glue-laminated members or I-joists are not permitted unless such penetrations are specifically considered in the design of the member or meet the manufacturers guidelines.		<p>Builder or framer should review this material placement layout prior to beginning construction of floor system. This layout DOES NOT supersede the plan set.</p>	<p>Squash blocks shall be installed under all point loads, and are to be greater than or equal to the dimensions of the post transferring the load from above.</p>
<p>Dimensions to any obstructions are approximate and should be field verified. Any discrepancies will be reported prior to floor installation.</p>		<p>All materials, (EWP, hangers etc.) shall be installed per manufacturer specific installation guides.</p>	

Job #