

= HUS26 (Qty. 10 ) ■ = THD26-2 (Qty. 3) = THDH210-3 (Qty. 1)

= HUS410 (Qty. 1)

Front Porch Beam (BBO)

Products Product Net Qty PlotID Plies Length BM2 (Dropped) 10' 0" 1-3/4"x 9-1/4" LVL Kerto-S GDH-3 (Dropped) 13' 0" 1-3/4"x 11-7/8" LVL Kerto-S BM1 (Flush) 12' 0" 1-3/4"x 11-7/8" LVL Kerto-S 3 SLGDH (Dropped) 1-3/4"x 18" LVL Kerto-S 22' 0"

2x12 SP No.2

20' 0"

**Truss Placement Plan SCALE:** 3/16" = 1'-0"

▲ = Denotes Left End of Truss (Reference Engineered Truss Drawing)

All Truss Reactions are Less than 3,000 lbs. Unless Noted Otherwise.

-- Denotes Reaction Greater than 3,000 lbs. Reaction / # of Studs

TY / CO.	TY / CO.   Harnett Co. / Harnett		deemed requiren attached requiren size and reaction 15000#. retained reaction Tables. retained	
DRESS	Lot 3 Fultz Farm	AD CHA GRASEL GRASEL OF LA GRASEL OF LA GRASEL OF LA GRASEL GRASE		RUS Reilly R Fayet Phon
DEL	Model	ART FO	y with the e contract derived f determin of wood s than 3000 red design a the supp eds those ed design the supp eded 1500	SES load Ir teville e: (910
TE REV. //	//	OR JAC 68 RECOUNTED 69 RECOUNTED 60 RECOUNTE	e prescriptor shall r rrom the pe the ministuds required the ministuds required the ministuds required the ministuds required to the ministuds required the ministuds required to the ministude the mi	& B ndustr s, N.C.
AWN BY	AWN BY Christine Shivy	() & (b))	tive Code efer to the orescriptive imum foou uired to se greater to ional shale em for all  Shi	ial Par 28309 -8787
LES REP.	_ES REP. Lenny Norris	#DS   Signature (Column)   Sig	e e ve Code indation upport han ill be // ttached I be	/IS

BUILDER	Southern Touch Homes	CITY / CO.	CITY / CO.   Harnett Co. / Harne
JOB NAME	JOB NAME Lot 3 Fultz Farm	ADDRESS	ADDRESS Lot 3 Fultz Farm
PLAN	Ryecroft	MODEL	Model
SEAL DATE   Seal Date	Seal Date	DATE REV. / /	//
QUOTE #	Ouote #	DRAWN BY	DRAWN BY Christine Shivy
# aor	J0420-1464	SALES REP.	SALES REP. Lenny Norris

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com