

Dimension Notes

1. All exterior wall to wall dimensions are to face of sheathing unless noted otherwise
2. All interior wall dimensions are to face of frame wall unless noted otherwise
3. All exterior wall to truss dimensions are to face of frame wall unless noted otherwise

All Walls Shown Are Considered Load Bearing

Plumbing Drop Notes

1. Plumbing drop locations shown are NOT exact.
2. Contractor to verify ALL plumbing drop locations prior to setting Floor Trusses.
3. Adjust spacing as needed not to exceed 24"oc.

Connector Information					Nail Information	
Sym	Product	Manuf	Qty	Supported Member	Header	Truss
	HUS410	USP	14	NA	16d/3-1/2"	16d/3-1/2"
	MSH422	USP	2	Varies	10d/3"	10d/3"
	HD410IF	USP	1	NA	16d/3-1/2"	10d/3"

Products								
PlotID	Length	Product	Plies	Net Qty				
BM1	22' 0"	1-3/4"x 16" LVL Kerto-S	3	3				
BM2	15' 0"	1-3/4"x 16" LVL Kerto-S	3	3				
BM3	7' 0"	1-3/4"x 9-1/4" LVL Kerto-S	2	2				
GDH	22' 0"	1-3/4"x 11-7/8" LVL Kerto-S	2	2				

Truss Placement Plan
Scale: 1/4"=1'

= Indicates Left End of Truss
(Reference Engineered Truss Drawing)
Do NOT Erect Truss Backwards

ROOF & FLOOR TRUSSES & BEAMS

Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

Bearing reactions less than or equal to 3000# are leemed to comply with the prescriptive Code equirements. The contractor shall refer to the ittached Tables (derived from the prescriptive Cod equirements) to determine the minimum foundatio size and number of wood studs required to support eactions greater than 3000# but not greater than 5000#. A registered design professional shall be etained to design the support system for any eaction that exceeds those specified in the attache Tables. A registered design professional shall be etained to design the support system for all eactions that exceed 15000#.

David Landry

David Landry

LOAD CHART FOR JACK STUDS

1700 1 2550 1 3400 1 3400 2 5100 2 6800 2 5100 3 7650 3 10200 3 6800 4 10200 4 13600 4 8500 5 12750 5 17000 5 10200 6 15300 6 11900 7 13600 8

15300 9

ADDRESS Josey Williams Rd.
MODEL Floor
DATE REV. 09/1/21
DRAWN BY David Landry
SALES REP. Bob Lewis

BUI LDERRegency HomesJOB NAMELot 1 Williams FarmPLANBrinkley "B" / GLSEAL DATEAnd the control of the control o

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

QUOTE ;