

= HUS26 (Qty. 21)

= JUS24 (Qty. 7)

▲ = Denotes Left End of Truss (Reference Engineered Truss Drawing) Truss Placement Plan
SCALE: 1/4" = 1'-0"

All Truss Reactions are Less than 3,000 lbs. Unless Noted Otherwise.

-- Denotes Reaction Greater than 3,000 lbs.

Reaction / # of Studs

ROOF & FLOOR

Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

TRUSSES & BEAMS

Bearing reactions less than or equal to 3000# are leemed to comply with the prescriptive Code equirements. The contractor shall refer to the ttached Tables (derived from the prescriptive Code equirements) to determine the minimum foundatio size and number of wood studs required to support eactions greater than 3000# but not greater than 5000#. A registered design professional shall be etained to design the support system for any eaction that exceeds those specified in the attacher ables. A registered design professional shall be etained to design the support system for all eactions that exceed 15000#.

Christine Shivy

Christine Shivy

LOAD CHART FOR JACK STUDS

(BASED ON TABLES ROOSE(I) & (b))
NUMBER OF JACK STUDS REQUIRED & EA END OF

NU	MBER C	IF JACI	K STUDS R HEADER/G		D & F	A END OF	
END REACHION (UP 10)	REQ'D STUDS FOR (2) PLY HEADER		SND REACTION (UP TD)	REQ15 STUDS FOR (3) ALY HEADER		END REACTION (UP TO)	REQUE STUDS FOR
1700	1		2550	1		3400	1
3400	2		5100	2		6800	2
5100	3		7650	3		10200	3
6800	4		10200	4		13600	4
8500	5		12750	5		17000	5
10200	6		15300	6			
11900	7						
13600	8						
15300	9						

CITY / CO. Erwin / Harnett
ADDRESS Josey Williams Road
MODEL
DAIE REV. / /
DRAWN BY Christine Shivy
SALES REP. Lenny Norris

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com


SEAL DATE

QUOTE 7

NAME

JOB

BUILDER



= HUS26 (Qty. 21)

= JUS24 (Qty. 7)

▲ = Denotes Left End of Truss
(Reference Engineered Truss Drawing)

Truss Placement Plan SCALE: 1/4" = 1'-0"

All Truss Reactions are Less than 3,000 lbs. Unless Noted Otherwise.

-- Denotes Reaction Greater than 3,000 lbs.

Reaction / # of Studs

ROOF & FLOOR TRUSSES & BEAMS

Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

paring reactions less than or equal to 3000# are seemed to comply with the prescriptive Code quirements. The contractor shall refer to the tached Tables (derived from the prescriptive Code quirements) to determine the minimum foundation are and number of wood studs required to support actions greater than 3000# but not greater than 3000#. A registered design professional shall be tained to design the support system for any action that exceeds those specified in the attached bles. A registered design professional shall be tained to design the support system for all actions that exceed 15000#.

Christine Shivy

Christine Shivy

LOAD CHART FOR JACK STUDS

(8ASED ON TABLÉS ROCEE(L) & (b))

NUMBER OF JACK STUDS RÉQUIRED © EA END OF
HEADED/GRODE

1901	MEEN C		16A068/			, e. c.	A CAD OF	
END REACHION (UP 10)	REQ'D STUDS FOR (2) PLY HEADER		END REACTION (UP TO)	CONTRACTOR	(3) ALY HEADER		END REACTION (UP TO)	REQUE STUDS FOR
1700	1		2550		1		3400	1
3400	2		5100		2		6800	2
5100	3		7650		3		10200	3
6800	4		10200		4		13600	4
8500	5		12750	1	5		17000	5
10200	6		15300	ı	6			
11900	7							
13600	8							
15300	9							

lopment	CI TY / CO.	CITY / CO. Erwin / Harnett
; Bluff	ADDRESS	ADDRESS Josey Williams Road
4" 3 Car	MODEL	Roof
	DATE REV. / /	//
	DRAWN BY	DRAWN BY Christine Shivy
	SALES REP.	SALES REP. Lenny Norris

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.
These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

SEAL DATE

Quote

QUOTE 7

Weaver Devel

BUILDER

Lot

JOB NAME