



16d/3-1/2"

10d/3"

THD26-2

USP 4

Roof Area = 2843.26 sq.ft. Ridge Line = 100.03 ft. Hip Line = 0 ft. Horiz. OH = 182.31 ft. Raked OH = 209.43 ft. Decking = 98 sheets

COMTECH **ROOF & FLOOR TRUSSES & BEAMS**

> Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

tearing reactions less than or equal to 3000# are eemed to comply with the prescriptive Code equirements. The contractor shall refer to the ttached Tables (derived from the prescriptive Code equirements) to determine the minimum foundativate and number of wood studs required to support eactions greater than 3000# but not greater than 5000#. A registered design professional shall be etained to design the support system for any eaction that exceeds those specified in the attacheables. A registered design professional shall be etained to design the support system for all eactions that exceed 15000#.

Bob Lewis

Bob Lewis

LOAD CHART FOR JACK STUDS (BASED ON TABLES R502.5(1) & (b))

NUM	MBER C	STUDS R HEADER/		A END OF	=
END REACTION (UP TO)	REQ'D STUDS FOR (2) PLY HEADER	END REACTION (UP TO)	REQ'D STUDS FOR (3) PLY HEADER	END RE <i>AC</i> TION (UP TO)	REQ'D STUDS FOR
1700	1	2550	1	3400	:
3400	2	5100	2	6800	i
5100	3	7650	3	10200	3
6800	4	10200	4	13600	4
8500	5	12750	5	17000	Ę
10200	6	15300	6		
11900	7				
13600	8				
15300	9				

BUILDER	JAY NORRIS	CITY / CO.	CITY / CO. BROADWAY / HARNETT	15300
JOB NAME	JOB NAME 117 KNIGHT RD	ADDRESS	117 KNIGHT RD	9
PLAN	CUSTOM	MODEL	ROOF	
SEAL DATE Seal Date	Seal Date	DATE REV . 10/31/24	10/31/24	
QUOTE#	Quote #	DRAWN BY Bob Lewis	Bob Lewis	
108#	J1024-5833	SALES REP.	Bob Lewis	

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.
These trusses are designed as individual building components to be incorporated into the building design at the specification of the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

= Indicates Left End of Truss (Reference Engineered Truss Drawing) Do NOT Erect Truss Backwards