## HARNETT COUNTY DEPARMENT OF PUBLIC HEALTH Well Abandonment Permit

Permit Number:Application Number: EH 2104-0007 Applicant Name: PTM L.P.
Address: 2201 NC 24-28
Type of Well: Total Dept: 48' Diameter: 24" Grouted: Mr Static Water Level: 16 Hand Dug Directions to Site: 6701 Corner of Sawyer Rd + NC 24-87
Directions to Site: Loton Corner of Sawyer Rd + NC 24-87
Agent of the State Mal AL NEHS Date: 4-22-21

Abandonment Procedure: Abandonment Procedure: 1. Remove all plumbing or piping into the well, along with any obstructions inside the well; 2.Remove as much of the well tile casing a possible, but no les than to a depth of three feet below land surface; 3. remove all soil or other subsurface material present down to the top of the remaining well casing, and extending to a width of at least 12 inches outside of the well casing on all sides; 4. Using 5 oz. of hypochlorite solution (such as HTH), disinfect the well in accordance with 15A NCAC 2C .0111 of this Subchapter. Do not use a common commercial household liquid bleach, as this is too weak a solution to ensure proper disinfection; 5. Fill the well up to the top of the remaining casing with cement grout, concrete grout, bentonite grout, dry clay, or material excavated during drilling of the well and then compacted in place; 6. Pour a one foot thick concrete grout or cement grout plug that fills the entire excavated area about the top of the casing, including the area extending on all sided of the casing out to a width of at least 12 inches on all sides; 7. Complete the abandonment process by filling the remainder of the well above the concrete or cement plug with additional concrete grout, cement grout, or soil.

Note: Contact Harnett County Environmental Health for appointment prior to beginning of well abandonment procedure.

## Well must be abandoned by a Certified North Carolina well driller/contractor.

