



NC 1-919-787-8787 / 1-800-473-8787 Fax 1-919-783-0617

VA 1-757-833-5300 / 1-800-868-8787 Fax 1-757-833-5400

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.

These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the entire truss support structure including, but not limited to headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult "Bracing of wood trusses" available from the Truss Plate Institute, 583 D'Onifrio Drive; Madison, WI 53179

TRUSS TO BEARING DESIGN RESPONSIBILITY.

Truss to bearing connections if shown on this layout are suggested by Truswood based solely on the uplift reactions and considerations for the truss component. All truss to bearing connections must be specified or approved by the Building Designer to adequately transfer all loads to the building system and foundation. Consult hardware manufacturer's specifications for all installation requirements.

- GENERAL NOTES:

 1.) REFER TO INDIVIDUAL TRUSS DRAWINGS FOR ADDITIONAL 1.) REFER TO INDIVIDUAL IRUSS DRAWNINGS FOR THE MINEO.
 2.) DIMENSIONS SHOWN ARE FROM FACE OF STUD OF BEARINGWALL U.N.O.
 3.) DIMENSIONAL VERIFICATION IS THE RESPONSIBILITY OF THESTE CONTRACTOR AND IOR ARCHITECT.
 4.) ALL INTERIOR HEADERS TO BE DROPPED EXCEPT AS NOTED.
 5.) ALL TRUSSES MUST BE SPACED AT A MAXIMUM OF 24" OCUNLESS OTHERWISE NOTED.
 6.) "DO NOT CUT, DRILL, OR ALTER ANY TRUSS WITHOUT THE"WRITTEN CONSENT FROM A REGISTERED ENGINEER.

I STORY TO THE ENGINEERS									
				DATE:	BY:	DATE:	BY:	DATE:	BY:
	26	FILENAME:	LOT:						
GO GOUSTOMER NAME: A SIND TIME TO THE COOK			SCALE: SCALE	#REVISION:	CKEE	REVISION:		REVISION:	
JOB NUMBER:									