

## All Walls Shown Are Considered Load Bearing

## Plumbing Drop Notes

Plumbing drop locations shown are NOT exact.
 Contractor to verify ALL plumbing drop locations prior to setting Attic Trusses.
 Adjust spacing as needed not to exceed 24"oc.

Roof Area = 4410.53 sq.ft. Ridge Line = 154.3 ft. Hip Line = 0 ft. Horiz. OH = 169.01 ft. Raked OH = 208.23 ft. Decking = 152 sheets


**Dimension Notes** 1. All exterior wall to wall dimensions are to face of sheathing unless noted otherwise

2. All interior wall dimensions are to face of frame wall unless noted otherwise 3. All exterior wall to truss dimensions are to face of frame wall unless noted otherwise



	Conne	Nail Information				
Sym	Product	Manuf	Qty	Supported Member	Header	Truss
	HUS26	USP	10	NA	16d/3-1/2"	16d/3-1/2"
	HUS410	USP	2	NA	16d/3-1/2"	16d/3-1/2"

ı			Durakasta					
	Products							
	PlotID	Length	Product	Plies	Net Qty			
	BM1	10' 0"	2x10 SPF No.1	2	2			
	BM2	21' 0"	1-3/4"x 11-7/8" LVL Kerto-S	2	2			
	BM3	7' 0"	1-3/4"x 9-1/4" LVL Kerto-S	2	4			
	GDH	34' 0"	1-3/4"x 11-7/8" LVL Kerto-S	2	2			



соттесн **ROOF & FLOOR TRUSSES & BEAMS** Reilly Road Industrial Park Fayetteville, N.C. 28309

Fax: (910) 864-4444 THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.
These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

Phone: (910) 864-8787

David Landry

David Landry

1700 1 3400 2 5100 3 6800 4 8500 5 1700 1 2550 1 3400 2 5100 2 5100 3 7650 3 6800 4 10200 4 8500 5 12750 5 10200 6 15300 6 (Reference Engineered Truss Drawing) 11900 7 13600 8 Do NOT Erect Truss Backwards

LOAD CHART FOR JACK STUDS (BASED ON TABLES R502.5(1) & (b))

NUMBER OF JACK STUDS REQUIRED @ EA END OF
HEADER/GIRDER

17000 5

= Indicates Left End of Truss