

JOB NAME SEAL DATE BUILDER QUOTE; THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. (Reference Engineered Truss Drawing)

COMTECH

**ROOF & FLOOR** 

TRUSSES & BEAMS

**Reilly Road Industrial Park** Fayetteville, N.C. 28309

Phone: (910) 864-8787 Fax: (910) 864-4444

aring reactions less than or equal to 3000# are emed to comply with the prescriptive Code quirements. The contractor shall refer to the ached Tables (derived from the prescriptive Code quirements) to determine the minimum foundatior ze and number of wood studs required to support actions greater than 3000# but not greater than i000#. A registered design professional shall be tained to design the support system for any action that exceeds those specified in the attacheables. A registered design professional shall be stained to design the support system for all pactions that exceed 15000#.

Marshall Naylor

Marshall Naylor

3400 1

6800 2

10200 3

13600 4

17000 5

Marshall Naylor

DRAWN BY

06/24/22

Marshall Naylor

SALES REP.

J0622-3392

Quote#

8/3/21

LOAD CHART FOR JACK STUDS

(BASED ON TABLES R502.5(1) & (b))

NUMBER OF JACK STUDS REQUIRED @ EA END OF HEADER/GIRDER

2550 1

5100 2

7650 3

10200 4

12750 5

15300 6

1700 1

3400 2

5100 3

6800 4

8500 5

10200 6

11900 7

13600 8 15300 9

Liberty Meadows

ADDRESS

Lot 44 Liberty Meadows Pickens C LF2, RP

A & G Residential

= Indicates Left End of Truss

Do NOT Erect Truss Backwards

Cameron /

CITY / CO.

HUS26

= 2nd Level Wall