

Plumbing Drop Notes . Plumbing drop locations shown are NOT exact. Contractor to verify ALL plumbing drop locations prior to setting Floor Trusses. 3. Adjust spacing as needed not to exceed 24"oc.

Dimension Notes All exterior wall to wall dimensions are to face of sheathing unless noted otherwise All interior wall dimensions are to face of stud unless noted otherwise 3. All exterior wall to truss dimensions are to face of stud unless noted otherwise

Roof Area = 2195.32 sq.ft. Ridge Line = 62.56 ft. Hip Line = 0 ft. Horiz. OH = 172.67 ft. Raked OH = 153.73 ft. Decking = 75 sheets

All Walls Shown Are Considered Load Bearing

▲ = Indicates Left End of Truss (Reference Engineered Truss Drawing) Do Not Erect Trusses Backwards



	Conne	Nail Information				
Sym	Product	Manuf	Qty	Supported Member	Header	Truss
	HUS410	USP	42	NA	16d/3-1/2"	16d/3-1/2"

Products									
PlotID	Length	Product	Plies	Net Qty					
FB3	9' 0"	1-3/4"x 14" LVL Kerto-S	2	2					
FB1	6' 0"	1-3/4"x 14" LVL Kerto-S	2	2					
FB4	22' 0"	1-3/4"x 18" LVL Kerto-S	3	3					
FB5	16' 0"	1-3/4"x 18" LVL Kerto-S	3	3					

= Indicates Left End of Truss (Reference Engineered Truss Drawing) Do NOT Erect Truss Backwards

COMTECH **ROOF & FLOOR TRUSSES & BEAMS**

> Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

g reactions less than or equal to 3000# are d to comply with the prescriptive Code ments. The contractor shall refer to the Cd Tables (derived from the prescriptive Cements) to determine the minimum foundated number of wood studs required to suppons greater than 3000# but not greater than

Signature Johnnie Baggett

Johnnie Baggett

LOAD CHART FOR JACK STUDS (BASED ON TABLES R502.5(1) & (b)) NUMBER OF JACK STUDS REQUIRED @ EA END OF HEADER/GIRDER

Lillington / Harnett Johnnie Baggett Paul Hawkins 1/2/24 DRAWN BY CITY / CO.

English Country Lot 146 Duncans New Home Inc The Holly Quote# JOB NAME BUILDER QUOTE

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.

These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.