

_			-				
LOAD CHART FOR JACK STUDS (BASED ON TABLES R502.5(1) & (b)) NUMBER OF JACK STUDS REQUIRED @ EA END OF			BUILDER	Hunter's Dream Homes	CITY / CO.	Johnston Co. / Johnston	THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design indentified on the placement drawing. The building designer
NO (10 Mg) (10	HEADER/GIRDER	ON FOR PER	JOB NAME	The Bradford Plan	ADDRESS	Site Address	is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com Bearing reactions less than or equal to 3000# are deemed to comply with the prescriptive Code requirements. The contractor shall refer to the attached Tables (derived from the prescriptive Code requirements) to determine the minimum foundation size and number of wood studs required to support reactions greater than 3000# but not greater than 15000#. A registered design professional shall be retained to design the support system for any reaction that exceeds those specified in the attached Tables. A registered design professional shall be retained to design the support system for all reactions that exceed 15000#. **David Landry** David Landry**
	END REACTI (UP TO) REQ'D STUDS (3) PLY HEA	END REACTIO (UP TO) REQ'D STUDS (4) PLY HEAD	PLAN	Bradford	MODEL	Roof	
	2550 1 5100 2 7650 3	3400 1 6800 2 10200 3	SEAL DATE	Seal Date	DATE REV.	03/12/24	
	10200 4 12750 5 15300 6	13600 4 17000 5	QUOTE#	Quote #	DRAWN BY	David Landry	
			JOB#	J0324-1480	SALES REP.	Lenny Norris	

соттесн

ROOF & FLOOR

TRUSSES & BEAMS Reilly Road Industrial Park

Fayetteville, N.C. 28309

Phone: (910) 864-8787

Fax: (910) 864-4444

____ = Indicates Left End of Truss (Reference Engineered Truss Drawing) Do NOT Erect Truss Backwards