


- NOT ALL TRUSSES ARE SYMMETRICAL AND MAY NOT PERFORM CORRECTLY IF INSTALLED BACKWARDS. PLEASE REFER TO SEALS WHILE SETTING TRUSSES TO ENSURE TRUSSES ARE ORIENTED CORRECTLY




THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss for more information. The building designer is responsible for temporary and permanent bracing of the roof system and for the overall structure. The design of the truss support structure including headers, beams, walls, columns, and floor joists is the responsibility of the building designer. For general guidance regarding bracing, consult "Bracing of Wood Trusses," available from the Truss Plate Institute, 583 D'Onofrio Ave., Madison, WI 53705.

Connector Summary		
Product	Manuf	Qty
HHUS410	Simpson	1
IUS2.56/14	Simpson	12
IUS2.56/14	Simpson	22



START HERE - SPACING 19.2" OC
UNLESS OTHERWISE NOTED

START HERE - SPACING 12" OC
UNLESS OTHERWISE NOTED



Roof Surface Area: **0 ft²** Sq. Ft.
Floor Surface Area: **8329 ft²** Sq. Ft.

Client: **MATTAMY HOMES**

Job Name: **VOYAGEUR - FARMHOUSE**

Model: **EWP 2ND FLOOR**

Lot #:	7	Subdivision:	FOX ETEI D EADM
--------	---	--------------	-----------------

Order #:	Sales Rep:	Designer:
----------	------------	-----------

Sales Rep: **C Walden**

Date: 3/14/2025

Hanger Conversion Chart

Simpson

LUS26

0790H

THJA26

THA422

733 RIVER PARK
DRIVE
DANVILLE VA 24540

(434) 793-0217
FAX: (434) 799-8767

Roof Surface Area: **0 ft²** Sq. Ft.
Floor Surface Area: **8329 ft²** Sq. Ft.