


- NOT ALL TRUSSES ARE SYMMETRICAL AND MAY NOT PERFORM CORRECTLY IF INSTALLED BACKWARDS. PLEASE REFER TO SEALS WHILE SETTING TRUSSES TO ENSURE TRUSSES ARE ORIENTED CORRECTLY



THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and system and for the overall structure. The design of the truss support structure including headers, beams, walls, columns, and sufficient blocking in floor cavity under point loads is the responsibility of the building designer. For general guidance regarding bracing, consult "Bracing of Wood Trusses" available from the Truss Plate Institute, 983 D'Onofrio Drive, Madison, WI 53719.

REVIEWED BY: _____ APPROVED BY: _____ DATE: _____

 RIVERSIDE ROOF TRUSS, LLC	733 RIVER PARK DRIVE DANVILLE, VA 24540 (434) 793-0217 FAX: (434) 799-8767		Hanger Conversion Chart		Client: MATTAMY HOMES
	USP	Simpson			Job Name: FFF-LOT #54 Roof
	JUS26	LUS26			Model: ELDORADO-LH-FH
	THD26	HUS26			Lot #: 54
	THD26-2	HHUS26-2			Subdivision: FOX FIELD FARM
	HJC26	THJA26	Order #: 25-0518-A	Sales Rep: C Walden	Designer: M N
	MSH422	THA422			Date: 3/24/2025
	Roof Surface Area: 2898 ft² Sq. Ft. Floor Surface Area: 1093 ft² Sq. Ft.				

=THIS SYMBOL INDICATES THE LEFT END OF TRUSS - REFER TO SEALED TRUSS DRAWINGS TO AVOID SETTING TRUSSES BACKWARDS!