

**WELL ABANDONMENT RECORD**

This form can be used for single or multiple wells

**1. Well Contractor Information:**

Regen W. Jackson  
Well Contractor Name (or well owner personally abandoning well on his/her property)

# 2179  
NC Well Contractor Certification Number

Jackson Well Co.  
Company Name

2. Well Construction Permit #: 29484  
List all applicable well permits (i.e. County, State, Variance, Injection, etc.) if known

**3. Well use (check well use):**

<b>Water Supply Well:</b>	
<input type="checkbox"/> Agricultural	<input type="checkbox"/> Municipal/Public
<input type="checkbox"/> Geothermal (Heating/Cooling Supply)	<input checked="" type="checkbox"/> Residential Water Supply (single)
<input type="checkbox"/> Industrial/Commercial	<input type="checkbox"/> Residential Water Supply (shared)
<input type="checkbox"/> Irrigation	
<b>Non-Water Supply Well:</b>	
<input type="checkbox"/> Monitoring	<input type="checkbox"/> Recovery
<b>Injection Well:</b>	
<input type="checkbox"/> Aquifer Recharge	<input type="checkbox"/> Groundwater Remediation
<input type="checkbox"/> Aquifer Storage and Recovery	<input type="checkbox"/> Salinity Barrier
<input type="checkbox"/> Aquifer Test	<input type="checkbox"/> Stormwater Drainage
<input type="checkbox"/> Experimental Technology	<input type="checkbox"/> Subsidence Control
<input type="checkbox"/> Geothermal (Closed Loop)	<input type="checkbox"/> Tracer
<input type="checkbox"/> Geothermal (Heating/Cooling Return)	<input type="checkbox"/> Other (explain under 7g)

4. Date well(s) abandoned: 10-31-17

**5a. Well location:**

Wyan Construction Inc.  
Facility/Owner Name  
Lot 67 Avery Rd  
Physical Address, City, and Zip  
HARNETT  
County  
F.U.  
Facility ID# (if applicable)  
          
Parcel Identification No. (PIN)

5b. Latitude and longitude in degrees/minutes/seconds or decimal degrees:  
(if well field, one lat/long is sufficient)

35° 30.061 N 78° 49.116 W

**CONSTRUCTION DETAILS OF WELL(S) BEING ABANDONED**

Attach well construction record(s) if available. For multiple injection or non-water supply wells ONLY with the same construction/abandonment, you can submit one form.

6a. Well ID#: # 1

6b. Total well depth: 10' (ft.)

6c. Borehole diameter: 48 (in.)

6d. Water level below ground surface: -0- (ft.)

6e. Outer casing length (if known): -0- (ft.)

6f. Inner casing/tubing length (if known): -0- (ft.)

6g. Screen length (if known): -0- (ft.)

For Internal Use ONLY:

**WELL ABANDONMENT DETAILS**

7a. Number of wells being abandoned: 1  
For multiple injection or non-water supply wells ONLY with the same construction/abandonment, you can submit one form.

7b. Approximate volume of water remaining in well(s): -0- (gal.)

**FOR WATER SUPPLY WELLS ONLY:**

7c. Type of disinfectant used: HTH 70%

7d. Amount of disinfectant used: 16 oz

**7e. Sealing materials used (check all that apply):**

- Neat Cement Grout
- Sand Cement Grout
- Concrete Grout
- Specialty Grout
- Bentonite Slurry
- Bentonite Chips or Pellets
- Dry Clay
- Drill Cuttings
- Gravel
- Other (explain under 7g)

**7f. For each material selected above, provide amount of materials used:**

Dry Clay 3yds  
Bentonite Chips 50lbs

**7g. Provide a brief description of the abandonment procedure:**

Dry Clay 7' Down  
Bentonite Chip 2' Down

8. Certification: 2179

Regen W. Jackson  
Signature of Certified Well Contractor or Well Owner  
11-5-17  
Date

By signing this form, I hereby certify that the well(s) was (were) abandoned in accordance with 15A NCAC 02C .0100 or 2C .0200 Well Construction Standards and that a copy of this record has been provided to the well owner.

**9. Site diagram or additional well details:**

You may use the back of this page to provide additional well site details or well abandonment details. You may also attach additional pages if necessary.

**SUBMITTAL INSTRUCTIONS**

10a. For All Wells: Submit this form within 30 days of completion of well abandonment to the following:

Division of Water Resources, Information Processing Unit,  
1617 Mail Service Center, Raleigh, NC 27699-1617

10b. For Injection Wells: In addition to sending the form to the address in 10a above, also submit one copy of this form within 30 days of completion of well abandonment to the following:

Division of Water Resources, Underground Injection Control Program,  
1636 Mail Service Center, Raleigh, NC 27699-1636

10c. For Water Supply & Injection Wells: In addition to sending the form to the address(es) above, also submit one copy of this form within 30 days of completion of well abandonment to the county health department of the county where abandoned.