

WELL ABANDONMENT RECORD

1. Well Contractor Information:

Bobby Furr Jr
 Well Contractor Name (or well owner personally abandoning well on his/her property)

2564-A
 NC Well Contractor Certification Number

B & S Well Drilling
 Company Name

2. Well Construction Permit #:

List all applicable well construction permits (i.e. UIC, County, State, Variance, etc.) if known

3. Well use (check well use):

Water Supply Well:	
<input type="checkbox"/> Agricultural	<input type="checkbox"/> Municipal/Public
<input type="checkbox"/> Geothermal (Heating/Cooling Supply)	<input checked="" type="checkbox"/> Residential Water Supply (single)
<input type="checkbox"/> Industrial/Commercial	<input type="checkbox"/> Residential Water Supply (shared)
<input type="checkbox"/> Irrigation	
Non-Water Supply Well:	
<input type="checkbox"/> Monitoring	<input type="checkbox"/> Recovery
Injection Well:	
<input type="checkbox"/> Aquifer Recharge	<input type="checkbox"/> Groundwater Remediation
<input type="checkbox"/> Aquifer Storage and Recovery	<input type="checkbox"/> Salinity Barrier
<input type="checkbox"/> Aquifer Test	<input type="checkbox"/> Stormwater Drainage
<input type="checkbox"/> Experimental Technology	<input type="checkbox"/> Subsidence Control
<input type="checkbox"/> Geothermal (Closed Loop)	<input type="checkbox"/> Tracer
<input type="checkbox"/> Geothermal (Heating/Cooling Return)	<input type="checkbox"/> Other (explain under 7g)

4. Date well(s) abandoned: 08/15/2020

5a. Well location:

Stacey Walker
 Facility/Owner Name

3705 Walker Road Linder NC
 Physical Address, City, and Zip

Barnett
 County

Parcel Identification No. (PIN)

5b. Latitude and longitude in degrees/minutes/seconds or decimal degrees: (if well field, one lat/long is sufficient)

_____ N _____ W

CONSTRUCTION DETAILS OF WELL(S) BEING ABANDONED

Attach well construction record(s) if available. For multiple injection or non-water supply wells ONLY with the same construction/abandonment, you can submit one form.

6a. Well ID#: _____

6b. Total well depth: 63 (ft.)

6c. Borehole diameter: 36 (in.)

6d. Water level below ground surface: 8 (ft.)

6e. Outer casing length (if known): 63 (ft.)

6f. Inner casing/tubing length (if known): none (ft.)

6g. Screen length (if known): none (ft.)

For Internal Use ONLY:

WELL ABANDONMENT DETAILS

7a. For Geoprobe/DPT or Closed-Loop Geothermal Wells having the same well construction/depth, only 1 GW-30 is needed. Indicate TOTAL NUMBER of wells abandoned: _____

7b. Approximate volume of water remaining in well(s): 600 (gal.)

FOR WATER SUPPLY WELLS ONLY:

7c. Type of disinfectant used: Hth

7d. Amount of disinfectant used: 5025

7e. Sealing materials used (check all that apply):

- Neat Cement Grout
- Bentonite Chips or Pellets
- Sand Cement Grout
- Dry Clay
- Concrete Grout
- Drill Cuttings
- Specialty Grout
- Gravel
- Bentonite Slurry
- Other (explain under 7g)

7f. For each material selected above, provide amount of materials used:

6yds of dry clay

18 bags of quickrete

7g. Provide a brief description of the abandonment procedure:

removed all pipes inside well,
removed 5ft of casing, poured
chlorine in, poured quickrete
and dry clay.

8. Certification:

Bobby Furr Jr 08/19/2020
 Signature of Certified Well Contractor or Well Owner Date

By signing this form, I hereby certify that the well(s) was (were) abandoned in accordance with 15A NCAC 02C.0100 or 2C.0200 Well Construction Standards and that a copy of this record has been provided to the well owner.

9. Site diagram or additional well details:

You may use the back of this page to provide additional well site details or well abandonment details. You may also attach additional pages if necessary.

SUBMITTAL INSTRUCTIONS

10a. For All Wells: Submit this form within 30 days of completion of well abandonment to the following:

Division of Water Resources, Information Processing Unit,
 1617 Mail Service Center, Raleigh, NC 27699-1617

10b. For Injection Wells: In addition to sending the form to the address in 10a above, also submit one copy of this form within 30 days of completion of well abandonment to the following:

Division of Water Resources, Underground Injection Control Program,
 1636 Mail Service Center, Raleigh, NC 27699-1636

10c. For Water Supply & Injection Wells: In addition to sending the form to the address(es) above, also submit one copy of this form within 30 days of completion of well abandonment to the county health department of the county where abandoned.