

Plumbing Drop Notes

1. Plumbing drop locations shown are NOT exact.

2. Contractor to verify ALL plumbing drop locations prior to setting Floor Trusses.

3. Adjust spacing as needed not to exceed 24"oc.

Dimension Notes

1. All exterior wall to wall dimensions are to face of stud unless noted otherwise

2. All interior wall dimensions are to face of stud unless noted otherwise


3. All exterior wall to truss dimensions are to face of stud unless noted otherwise

Roof Area = 2515.23 sq.ft.
Ridge Line = 73.31 ft.
Hip Line = 0 ft.
Horiz. OH = 203.25 ft.
Raked OH = 236.27 ft.
Decking = 86 sheets

All Walls Shown Are Considered Load Bearing

▲ = Indicates Left End of Truss (Reference Engineered Truss Drawing) Do Not Erect Trusses Backwards

 $\underbrace{ 1 \frac{\text{Truss Placement Plan}}{\text{Scale: NTS}} }$



2nd Floor Walls @ 8' 1 1/2" UNO

Products					
PlotID	Length	Product	Plies	Net Qty	
BM1	16' 0"	1-3/4"x 14" LVL Kerto-S	2	2	
BM2	12' 0"	1-3/4"x 9-1/4" LVL Kerto-S	2	2	
BM3	7' 0"	1-3/4"x 14" LVL Kerto-S	2	2	
BM4	6' 0"	1-3/4"x 9-1/4" LVL Kerto-S	2	2	
BM5	7' 0"	1-3/4"x 14" LVL Kerto-S	2	2	
BM6	6' 0"	1-3/4"x 9-1/4" LVL Kerto-S	2	2	
BM7	8' 0"	1-3/4"x 9-1/4" LVL Kerto-S	2	2	
GDH	22' 0"	1-3/4"x 23-7/8" LVL Kerto-S	2	2	

Connector Information				Nail Information		
Sym	Product	Manuf	Qty	Supported Member	Header	Truss
	HUS410	USP	10	BM1, BM3	16d/3-1/2"	16d/3-1/2"
	MSH422	USP	12	F01G, F04G, F07G	10d/3"	10d/3"
	THD410	USP	4	B2-GRD	16d/3-1/2"	10d/3"
	HUS26	USP	8	Varies	16d/3-1/2"	16d/3-1/2"
	JUS26	USP	5	Varies	10d/3"	10d/3"



Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

Bearing reactions less than or equal to 3000# are deemed to comply with the prescriptive Code requirements. The contractor shall refer to the attached Tables (derived from the prescriptive Code requirements) to determine the minimum foundation size and number of wood studs required to support reactions greater than 3000# but not greater than 15000#. A registered design professional shall be retained to design the support system for any reaction that exceeds those specified in the attached Tables. A registered design professional shall be retained to design the support system for all reactions that exceed 15000#.

Signatur


Neil Baggett

LOAD CHART FOR JACK STUDS

COUNTY	Harnett
ADDRESS	Lot 60 Summerlin
MODEL	Floor
DATE REV.	6/15/2020
DRAWN BY	Neil Baggett
SALESMAN	SALESMAN Neil Baggett

BUILDERPrecision Custom Homes & RenovationsJOB NAMELot 60 SummerlinPLANWyatt 2.0/6LSEAL DATEN/AQUOTE #N/AJOB ##J0620-2672

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com



Plumbing Drop Notes Plumbing drop locations shown are NOT exact.
 Contractor to verify ALL plumbing drop locations prior to setting Floor Trusses.

Adjust spacing as needed not to exceed 24"oc

Dimension Notes All exterior wall to wall dimensions are to face of stud unless noted otherwise
 All interior wall dimensions are to face of stud unless noted otherwise
3. All exterior wall to truss dimensions are to face of stud unless noted otherwise

Roof Area = 2515.23 sq.ft. Ridge Line = 73.31 ft. Hip Line = 0 ft. Horiz. OH = 203.25 ft. Raked OH = 236.27 ft. Decking = 86 sheets

All Walls Shown Are Considered Load Bearing

= Indicates Left End of Truss (Reference Engineered Truss Drawing) Do Not Erect Trusses Backwards

Hatch Legend Flush Beam Drop Beam

Mechanical & Light Box Storage

2nd Floor Walls @ 8' 1 1/2" UNO

Truss Placement Plan
Scale: NTS

PlotID Length Product Plies Net Qty 1-3/4"x 9-1/4" LVL Kerto-S BM3 1-3/4"x 14" LVL Kerto-S BM4 1-3/4"x 9-1/4" LVL Kerto-S BM5 7' 0" 1-3/4"x 14" LVL Kerto-S 2 BM6 2 1-3/4"x 9-1/4" LVL Kerto-S BM7 1-3/4"x 9-1/4" LVL Kerto-S 2 8' 0"

Connector Information				Nail Information		
Sym	Product	Manuf	Qty	Supported Member	Header	Truss
	HUS410	USP	10	BM1, BM3	16d/3-1/2"	16d/3-1/2"
	MSH422	USP	12	F01G, F04G, F07G	10d/3"	10d/3"
	THD410	USP	4	B2-GRD	16d/3-1/2"	10d/3"
	HUS26	USP	8	Varies	16d/3-1/2"	16d/3-1/2"
	JUS26	USP	5	Varies	10d/3"	10d/3"

1-3/4"x 23-7/8" LVL Kerto-S 2

COMTECH **ROOF & FLOOR TRUSSES & BEAMS**

Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

Bearing reactions less than or equal to 3000# are deemed to comply with the prescriptive Code requirements. The contractor shall refer to the attached Tables (derived from the prescriptive Code requirements) to determine the minimum foundation size and number of wood studs required to support reactions greater than 3000# but not greater than 15000#. A registered design professional shall be retained to design the support system for any reaction that exceeds those specified in the attached Tables. A registered design professional shall be retained to design the support system for all reactions that exceed 15000#.

Neil Baggett

LOAD CHART FOR JACK STUDS

(BASED ON TABLES R502.5(1) & (b)) NUMBER OF JACK STUDS REQUIRED @ EA END OF HEADER/GIRDER END REACTIC (UP TO) REQ'D STUDS (4) PLY HEAD

3400 1 1700 1 2550 1 3400 2 5100 2 6800 2 5100 3 7650 3 10200 3 6800 4 10200 4 13600 4 8500 5 12750 5 17000 5 10200 6 15300 6 11900 7 13600 8

15300 9

Harnett

COUNTY

Neil Baggett Neil Baggett 6/15/2020 9 Pot Fot SALESMAN DRAWN BY DATE REV. ADDRESS

ations Renov Precision Custom Homes & 2.0/*G*L J0620-2671 Lot 60 Wyatt ? N/A Z A JOB NAME SEAL DATE QUOTE # BUILDER PLAN JOB

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.

These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

russ delivery package or online @ sbcindustry.co