

TO USE:

- Select the required spans and depth.
- Determine the support condition for the nearest bearing, end support or interior support (including cantilever-end supports).
- Select the row corresponding to the required Clear Span. For spans between those listed use the next largest value.
- Select the column corresponding to the required hole diameter. For diameters between those listed, use the next largest value.
- The intersection of the Clear Span row and Hole Diameter column gives the maximum distance from the hole face of bearing to the center of a circular hole.
- Double check the distance to the other support, using the appropriate support condition.


Depth	Clear Span (ft)	Distance from End Support										Distance from Interior or Cantilever-End Support									
		Hole Diameter										Hole Diameter									
		2"	4"	6"	8"	10"	12"	2"	4"	6"	8"	10"	12"	2"	4"	6"	8"	10"	12"		
14'	14'	1'-0"	1'-0"	1'-0"	1'-0"	2'-2"	-	1'-0"	1'-0"	1'-5"	2'-7"	3'-9"	-	1'-0"	1'-0"	1'-5"	2'-7"	3'-9"	-		
	18'	1'-0"	1'-0"	1'-9"	3'-1"	4'-6"	-	1'-8"	2'-10"	3'-11"	5'-1"	6'-3"	-	1'-0"	1'-0"	1'-5"	2'-7"	3'-9"	-		
	22'	1'-5"	2'-9"	4'-1"	5'-6"	7'-0"	-	4'-2"	5'-4"	6'-5"	7'-7"	8'-9"	-	1'-0"	1'-0"	1'-5"	2'-7"	3'-9"	-		
	26'	3'-8"	5'-0"	6'-5"	8'-0"	9'-8"	-	6'-8"	7'-10"	8'-11"	10'-1"	11'-4"	-	1'-0"	1'-0"	1'-5"	2'-7"	3'-9"	-		
16'	18'	1'-0"	1'-0"	1'-4"	2'-5"	3'-7"	4'-11"	1'-6"	2'-6"	3'-6"	4'-6"	5'-6"	6'-6"	1'-0"	1'-0"	1'-5"	2'-7"	3'-9"	-		
	22'	1'-8"	2'-5"	3'-6"	4'-9"	6'-1"	7'-5"	4'-0"	5'-0"	6'-0"	7'-0"	8'-0"	9'-0"	1'-0"	1'-0"	1'-5"	2'-7"	3'-9"	-		
	26'	3'-4"	4'-8"	5'-11"	7'-2"	8'-7"	10'-1"	6'-6"	7'-6"	8'-6"	9'-6"	10'-6"	11'-6"	1'-0"	1'-0"	1'-5"	2'-7"	3'-9"	-		
	30'	5'-9"	7'-0"	8'-4"	9'-9"	11'-3"	12'-10"	9'-0"	10'-0"	11'-0"	12'-0"	13'-2"	14'-8"	1'-0"	1'-0"	1'-5"	2'-7"	3'-9"	-		

DESIGN ASSUMPTIONS:

- The hole locations listed above are valid for floor joists supporting only uniform loads. The total uniform load shall not exceed 130 psf (e.g., 40 psf Live Load and 25 psf Dead Load spaced 24" oc).
- Hole location is measured from the inside face of bearing to the center of a circular hole, from the closest support.
- Clear Span has not been verified for these joists and is shown for informational purposes only! Verify that the joist selected will work for the span and loading conditions needed before checking hole location.
- The maximum hole depth for circular holes is the joist depth less 4"; except the maximum hole depth is 6" for 9-1/2" LPI joists and 8" for 11-7/8" LPI joists.
- Holes cannot be located in the span where designated "-", without further analysis by a design professional.

NOTES:

- Holes may be placed anywhere within the depth of the joist. A minimum 1/4" clear distance is required between the hole and the flanges.
- Round holes up to 1 1/2" diameter may be placed anywhere in the web.
- Perforated "rockholes" may be neglected when locating web holes.
- Holes larger than 1-1/2" are not permitted in cantilevers without special engineering.
- Multiple holes shall have a clear separation along the length of the joist of at least twice the length of the larger adjacent hole, or a minimum of 12" center-to-center, whichever is greater.
- Multiple holes may be spaced closer provided they fit within the boundary of an acceptable larger hole. Example: two 3" round holes, aligned parallel to the joist length may be spaced 2" apart (clear distance) provided that a 3" high by 8" long rectangle or an 8" diameter round hole are acceptable for the joist depth at that location and completely encompass the holes.
- For conditions not covered in this table, use LP's design software or contact your local LPI Sales/Start* Engineered Wood Products distributor for more information.




Important Notes:

WARNING: Failure to follow proper procedures for handling, storage and installation could result in unsatisfactory performance, voiding.

Handling & Storage:

- Keep LPI JoistStart* Joists, LPI JoistStart* LVLs, LPI JoistStart* LVLs, LVLs dry.
- Unload products carefully by lifting. Support the bundles to reduce excessive bending. Individual products should be handled in a manner which prevents excessive damage during unloading, unloading, and storage.
- Keep bundles in the vertical.
- Keep bundles in the vertical.
- Do not use chains or cables to move bundles.
- Do not use chains or cables to move bundles.
- Do not use chains or cables to move bundles.



2nd Flr

Label	Description	Width	Depth	Qty	Plies	Pcs	Length
J8	LPI 20Plus	2.5	14			1	30'-0"
J7	LPI 20Plus	2.5	14			4	30'-0"
J5	LPI 20Plus	2.5	14			5	30'-0"
J4	LPI 20Plus	2.5	14			2	18'-0"
J10	LPI 20Plus	2.5	14			3	16'-0"
J6	LPI 20Plus	2.5	14			3	16'-0"
J9	LPI 20Plus	2.5	14			6	14'-0"
J2	LPI 20Plus	2.5	14			2	14'-0"
J3	LPI 20Plus	2.5	14			6	12'-0"
J1	LPI 20Plus	2.5	14			3	4'-0"

LVL LVL (Chalk)

Label	Description	Width	Depth	Qty	Plies	Pcs	Length
FB1-4B	LPI-SL 1.55E	3.5	14			1	8'-0"
FB1-4A	LPI-SL 1.55E	3.5	14			1	8'-0"
FB3	LPI-SL 1.55E	3.5	14			1	24'-0"
FB1	LPI-SL 2000F-2.0E	1.75	24	1	2	2	24'-0"

LVL LVL (Dropped)

Label	Description	Width	Depth	Qty	Plies	Pcs	Length
DB3-A	LPI-SL 1.55E	3.5	9.25			2	12'-0"
DB1	LPI-SL 1.55E	3.5	9.25			1	8'-0"
DB2	LPI-SL 1.55E	3.5	11.875			1	24'-0"

Beam Br Chalk (Dropped)

Label	Description	Width	Depth	Qty	Plies	Pcs	Length
DB1	LPI-SL 1.55E	3.5	9.25			2	14'-0"
DB3	LPI-SL 1.55E	3.5	9.25			2	12'-0"
DB2	LPI-SL 1.55E	3.5	11.875			2	24'-0"

Rim Board

Label	Description	Width	Depth	Qty	Plies	Pcs	Length
R1	LPI APA Rated OSB 1.125 X 14	1.125	14			12	12'-0"

Hanger

Label	Pcs	Description	Skew	Slope	Fasteners	Supported Member
H1	25	H152.5x14 (Min)			12 10d	

2ND FLOOR FRAMING

SCALE: 1/4" = 1'

Legend:

- 3.5" Non-Big Wall
- Wall
- Partition Wall (Non-Load-Bearing)
- Wall Opening
- LPI APA Rated OSB 1.125 X 14
- LPI 20Plus 14
- LPI-SL 1.55E 3.5 X 9.25 (Dropped)
- LPI-SL 1.55E 3.5 X 11.875 (Dropped)
- LPI-SL 1.55E 3.5 X 14
- LPI-SL 2000F-2.0E 1.75 X 24
- 1.5 X 9.25 (Dropped)

Fastener

- Nailed & Glued

Calculated
Structural
Designs

2160 Satellite Blvd., Suite 450
Duluth, GA 30097
888-613-5078

Build on what we know™

Dealer
84 Lumber-Fayetteville #2307
Fayetteville, NC 28301
(910) 875-9185

Project
CL2302 CP GL

Created
January 29, 2015

Layout Name
CL2302 CP GL

Description
Customs Land
CL2302 CP GL

Designer
Kyle Miltner

Revised
April 06, 2020

2nd Flr

Design Method ASD (USA)

Building Code IRC/IRC 2015

Floor

Loads

- Live 40
- Dead 10

Deflection Joist

- LL Span L 440
- TL Span L 240
- LL Cant 2L 360
- TL Cant 2L 360
- Deflection Girders
- LL Span L 360
- TL Span L 240
- LL Cant 2L 360
- TL Cant 2L 360

Decking

- OSB 23/32 APA Rated 5/8" Thick
- Nailed & Glued

© 2020 LP Lumber. All rights reserved. This document is for informational purposes only. It is not to be used in conjunction with the structural and structural design, but to supplement.


**THIS LAYOUT IS INTENDED FOR THE PURPOSE OF TRUSS LOCATION AND PLACEMENT ONLY.
REFER TO THE BUILDING PLANS FOR ACTUAL BUILDING CONSTRUCTION.**

GENERAL NOTES:

DO NOT CUT OR MODIFY TRUSSES.
TRUSSES ARE SPACED 24" ON CENTER UNLESS NOTED OTHERWISE.

REFER TO THE INDIVIDUAL TRUSS DESIGN DRAWINGS FOR THE LOCATION OF LATERAL BRACING AND MULTI-PLY CONNECTION REQUIREMENTS.

PER ANSI TPI 1-2002 THE TRUSS ENGINEER IS RESPONSIBLE FOR TRUSS TO TRUSS CONNECTIONS AND TRUSS PLY TO PLY CONNECTIONS. THIS TRUSS PLACEMENT PLAN RECOMMENDS TRUSS TO BEARING CONNECTIONS AND TRUSS TO BEAM CONNECTIONS WHICH SHALL BE REVIEWED BY THE BUILDING DESIGNER. IT IS THE RESPONSIBILITY OF THE BUILDING DESIGNER TO RESOLVE ALL ROOF FORCES ADEQUATELY TO THE FOUNDATION.



Hardware List:		
A	4	THJA26
B	-	-
C	-	-
D	-	-
-	-	-
-	-	-
-	-	-

ROOF LOADING:
TOP LIVE: 20 PSF
TOP DEAD: 10 PSF
BOTTOM DEAD: 10 PSF
WIND SPEED: 115 MPH



84 LUMBER COMPONENTS

DEDICATED TO QUALITY AND EXCELLENCE
200 EMMETT ROAD
DUNN, NORTH CAROLINA 28334
PHONE: 910-892-8400

PROJECT:	-		
CUSTOMER:	Caviness Land		
MODEL:	CL2302 No CP GOL		
SCALE:	NOT TO SCALE	P.O. NUMBER: XXXXX	ORDER: 12348
DRAWN BY:	RE	PRINT DATE: //	REV: 05/24/17 14:11:18
			SHIP DATE: 06/08/17