

ROOF & FLOOR TRUSSES & BEAMS

Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

Bearing reactions less than or equal to 3000# are deemed to comply with the prescriptive Code requirements. The contractor shall refer to the attached Tables (derived from the prescriptive Cod requirements) to determine the minimum foundatic size and number of wood studs required to support reactions greater than 3000# but not greater than 15000#. A registered design professional shall be retained to design the support system for any reaction that exceeds those specified in the attache Tables. A registered design professional shall be retained to design the support system for all reactions that exceed 15000#.

David Landry

David Landry

LOAD CHART FOR JACK STUDS

(BASED ON TABLES ROUZE(I) & (b)) NUMBER OF JACK STUDS REQUIRED & EA END O

NUA	WBER C	F JAC	K STUBS R HEADERA		A END	OF
EXB REACTION (0P 10)	REQ'D STUDS FOR (2) PLY HEADER		ENS REACTION (UP TO)	REQ15 STUBS FOR (3) ALY HEADER	END REACTION (UP TO)	REQUE STUDS FOR (4) PLY HEADER
1700	1		2550	1	3400	0 1
3400	2		5100	2	6800	
5100	3		7650	3	1020	0 3
6800	4		10200	4	1360	0 4
8500	5		12750	5	1700	0 5
10200	6		15300	6		
11900	7					
13600	8					
15300	9					

CI TY / CO.	CI TY / CO. Spring Lake / Cumberland
ADDRESS	10 North Dakota Ct.
MODEL	Roof
DATE REV.	09/18/20
DRAWN BY	DRAWN BY David Landry
SALES REP.	SALES REP. Marshall Naylor

Villas Benjamin Stout Sierra J0920-4178 Quote 14 N/A Lot SEAL DATE NAME # BUILDER QUOTE PLAN JOB THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.

= Indicates Left End of Truss
(Reference Engineered Truss Drawing)
Do NOT Erect Truss Backwards