



All Truss Reactions are Less than 3,000 lbs. Unless Noted Otherwise.



-- Denotes Reaction Greater than 3,000 lbs.

Reaction / # of Studs

	Conne	ctor Info	Nail Information			
m	Product	Manuf	Qty	Supported Member	Header	Truss
	HUS26	USP	13	Varies	16d/3-1/2"	16d/3-1/2"



▲ = Indicates Left End of Truss (Reference Engineered Truss Drawing) Do Not Erect Trusses Backwards

Plumbing Drop Notes

1. Plumbing drop locations shown are NOT exact.
2. Contractor to verify ALL plumbing drop locations prior to setting Floor Trusses.
3. Adjust spacing as needed not to exceed 24°oc.

Dimension Notes

1. All exterior wall to wall dimensions are to face of sheathing unless noted otherwise
2. All interior wall dimensions are to face of stud unless noted otherwise

All exterior wall to truss dimensions are to face of stud unless noted otherwise

ROOF & FLOOR TRUSSES & BEAMS

> Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

Bearing reactions less than or equal to 3000# are deemed to comply with the prescriptive Code requirements. The contractor shall refer to the attached Tables ( derived from the prescriptive Code requirements ) to determine the minimum foundation size and number of wood studs required to support reactions greater than 3000# but not greater than 15000#. A registered design professional shall be retained to design the support system for any reaction that exceeds those specified in the attached Tables. A registered design professional shall be retained to design the support system for all reactions that exceed 15000#.

Signature\_

Sales Area

LOAD CHART FOR JACK STUDS

-	COUNTY	Harnett County
	ADDRESS	Lot 58 South Creek / Lillington, NC
	MODEL	Roof
	DATE REV.	12/8/20
	DRAWN BY	DRAWN BY Anthony Williams
	SALESMAN	SALESMAN Anthony Williams

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

PLAN

11/12/19

SEAL DATE

Z

QUOTE#

Signature Home Builders

BUILDER

58

JOB NAME

Truss Placement Plan SCALE: 3/16" = 1'-0"