



All Truss Reactions are Less than 3,000 lbs. Unless Noted Otherwise.

-- Denotes Reaction Greater than 3,000 lbs. Reaction / # of Studs

Connector Information				Nail Information		
Sym	Product	Manuf	Qty	Supported Member	Header	Truss
	HUS26	USP	13	Varies	16d/3-1/2"	16d/3-1/2"

WALL SCHEDULE						
1st Floor Brg. Wall						
2nd Floor Brg. Wall						
⊏⊒⊒⊒⊐ Non-Bearing Walls						

= Indicates Left End of Truss (Reference Engineered Truss Drawing) Do Not Erect Trusses Backwards

Plumbing Drop Notes Plumbing drop locations shown are NOT exact.
 Contractor to verify ALL plumbing drop locations prior to setting Floor Trusses.
 Adjust spacing as needed not to exceed 24"oc.

Dimension Notes Dimension Notes

1. All exterior wall to wall dimensions are to
face of sheathing unless noted otherwise
2. All interior wall dimensions are to face of
stud unless noted otherwise
3. All exterior wall to truss dimensions are to
face of stud unless noted otherwise



Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

Bearing reactions less than or equal to 3000# are deemed to comply with the prescriptive Code requirements. The contractor shall refer to the attached Tables ( derived from the prescriptive Code requirements ) to determine the minimum foundation size and number of wood studs required to support reactions greater than 3000# but not greater than 15000#. A registered design professional shall be retained to design the

Sales Area

LOAD CHART FOR JACK STUDS (BASED ON TABLES R502.5(1) & (b))

NUMBER OF JACK STUDS REQUIRED @ EA END OF HEADER/GIRDER 3400 1 2550 1

1700 1 3400 2 5100 2 6800 2 5100 3 7650 3 10200 3 13600 4 6800 4 10200 4 8500 5 12750 5 17000 5 10200 6 15300 6 11900 7 13600 8

15300 9

Z Dunn, Williams Anthony Williams Harnett County 5 Pope Anthony 2/18/21 Lot SALESMAN

DRAWN BY DATE REV. ADDRESS COUNTY Signature Home Builders Gar. Plan Date: 11/12/19 Mayview w/ 3rd 5 Pope Road Z

JOB NAME SEAL DATE QUOTE# BUILDER PLAN THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

russ delivery package or online @ sbcindustry.co

J0221-0977

**Truss Placement Plan** SCALE: 3/16" = 1'-0"