


REVISIONS	DATE	DESCRIPTION
1	X	
2	X	
3	X	
4	X	

Sumter Truss Plant
 P.O. BOX 1546
 SUMTER, SC 29151
 PHONE: (803) 778-1921
 FAX: (803) 773-4731

Sumter Truss Plant
 P.O. BOX 1546
 SUMTER, SC 29151
 PHONE: (803) 778-1921
 FAX: (803) 773-4731



DRAWN BY
 JR
 DATE
 7/11/18
 JOB NUMBER
 XXXXXX
 SHEET NUMBER
 1 of 1

ROOF TRUSS NOTES:

- DO NOT CUT DRILL NOTCH OR OTHERWISE DAMAGE TRUSSES. Contact BCS Representative for assistance PRIOR TO modifying any truss. *Espanol - NO CORTE, REFORZO, HAGA MUECASCAS O DAME REPRESENTANTE DE BCS PARA ASISTENCIA ANTES DE realizar cualquier modificación.*
- This Truss Placement Diagram is intended to serve as a guide for truss installation. The Diagram has been prepared by a qualified truss technician and is not an engineered drawing.
- The responsibilities of the Owner, Building Designer, Contractor, Truss Designer and Truss Manufacturer are defined in the Truss Manufacturer's Truss Design Manual.
- The wood components shown on this diagram are to be used in dry service (moisture content < 19%) and non-ferrous fasteners shall be used. All truss members and hangers are galvanized to the G60 Standard unless noted otherwise.
- Refer to the Truss Design Drawings for specific details.
- The Truss Technician shall provide Truss-to-Truss Connection Requirements. Any special or other requirements shall be noted on the Truss Design Drawing.
- The Truss Placement Diagram and Truss Design Drawings are the property of Builders FirstSource and shall not be reproduced, copied, or used in whole or in part without the prior written authorization.
- In some cases, field framing may be required to support the trusses. The location and appearance shown on the Connection Documents.
- Field framing, including valley rafters, installed over trusses shall be supported by a minimum of 4" on center (O.C.) or less. Stagger knee braces from adjacent rafters such that the load is distributed uniformly over multiple truss members. Do not concentrate at one location or along one truss.
- Truss Top Chords shall be fully sheathed or have sheathing applied to the top chord. The Truss Bottom Chord End Panel shall not exceed the maximum shown on the Truss Design Drawing. Field framing bottom chord floor or ceiling attachments shall be applied to the Truss Design Drawing. Field framing shall be supported by a minimum of 4" on center (O.C.) or less.
- The Placement Diagram is based upon the following assumptions: Trusses are to be installed dimensionally correct, square, plumb, and level to adequately support the trusses. The foundation design, framing, and other conditions shall be in accordance with applicable building code are the responsibility of the Owner, Building Designer, and Contractor.
- The Contractor shall be responsible for this project. Refer to the Mike Piggyback Connection Detail applicable for the project details and wind load category.
- The Contractor shall follow the SBCCA TTB Partition Separation Prevention and Solutions for truss attachment to non-load bearing walls and carefully follow the details to avoid gypsum wall board related issues.

WARNING:
 TRUSSES MUST BE BRACED DURING INSTALLATION. FAILURE TO DO SO MAY RESULT IN INJURY OR DEATH. *Espanol - (TRUSSES) DEBERAN TENER UN SOPORTE DURANTE LA INSTALACION. EL FALTA DE PODRIA RESULTAR EN LESIONES O MUERTE.*

Trusses shall not be installed in a manner meeting all of the following criteria:
 1. Failure to follow these specifications may result in injury or death.
 2. Trusses under construction are vulnerable to high winds and present a possible safety hazard. The Contractor is responsible for recognizing adverse weather conditions and shall take appropriate action to protect the trusses.
 3. BCS INSTRUCTIONS SHALL BE FOLLOWED:
 BCS181 = Safe Truss Handling and Installation
 BCS182 = Permanent Restraint
 BCS183 = Permanent Restraint
 BCS184 = Safe Construction Loading
 BCS185 = Truss Damage and Modification Guidelines
 BCS186 = Truss Damage and Modification Guidelines
 BCS188 = Truss-to-Truss Connections
 BCS189 = Multi-Ply Girders
 BCS190 = Full Frame Truss Installation
 BCS191 = Full Frame Truss Installation (>80').

SIMPSON CONNECTOR SCHEDULE

HANGER TYPE	QTY	CARRYING MEMBER	CARRIED MEMBER	CARRYING MEMBER	CARRIED MEMBER
HTL-26	17	20-164	20-104 x 1/2"	B03, FG01	A12-15
HTL-26	6	20-164	20-104 x 1/2"	JDI, Ledger	C0-02, J01-02
HTL-26	2	20-164	20-104 x 1/2"		A11-12
HTL-26-2	1	20-164	20-104 x 1/2"	A10	2-2X10
LUS-24	14	4-104	2-104	FG01	J03





PLATE ID	Length	Product	LVL	PLIES	NEL QTY
BM-2	14' 0"	1 3/4" x 9 1/4" L9E Microllam®	LVL	3	3
BM-1	10' 0"	1 3/4" x 9 1/4" L9E Microllam®	LVL	2	2
GDH-1	22' 0"	1 3/4" x 11 7/8" L9E Microllam®	LVL	3	3
GDH-SL	22' 0"	1 3/4" x 15" L9E Microllam®	LVL	3	3



THE SUGGESTED TRUSS MANUFACTURER'S CONNECTIONS AND TIEBACKS FOR GRANTY MEMBER OF RECORD, PER PART 1.002, ARE SUBJECT TO WALL AND TRUSS TO TRUSS CONNECTIONS ARE THE RESPONSIBILITY OF THE TRUSS MANUFACTURER.

