

Truss Placement Plan

SCALE: 1/4" = 1'0"

(Reference Engineered Truss Drawing)

▲= Denotes Left End of Truss

All Truss Reactions are Less than 3,000 lbs. Unless Noted Otherwise.

-- Denotes Reaction Greater than 3,000 lbs. Reaction / # of Studs

= THD26-2 (Qty. 1)
= HUS26 (Qty. 8)

		Products		
PlotID	Length	Product	Plies	Net Qty
GDH-3 (dropped)	13' 0"	1-3/4"x 11-7/8" LVL Kerto-S	2	2
GDH (dropped)	23' 0"	1-3/4"x 14" LVL Kerto-S	2	2



TRUSSES & BEAMS

Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

Bearing reactions less than or equal to 3000# are deemed to comply with the prescriptive Code requirements. The contractor shall refer to the attached Tables (derived from the prescriptive Code requirements) to determine the minimum foundation size and number of wood studs required to support reactions greater than 3000# but not greater than 15000#. A registered design professional shall be retained to design the support system for any reaction that exceeds those specified in the attached Tables. A registered design professional shall be retained to design the support system for all reactions that exceed 15000#.


Lenny Norris

LOAD CHART FOR JACK STUDS
(BASED ON TABLES ROCES(I) & (b))

COUNTY	Harnett
ADDRESS	Lot 4 Atkins Farm
MODEL	Model
DATE REV. / /	//
DRAWN BY	DRAWN BY Lenny Norris
SALESMAN	SALESMAN Lenny Norris

JOB NAME	Lot 4 Atkins Farm
PLAN	Sinclair (190320B)
SEAL DATE Seal Date	Seal Date
QUOTE #	Ouote #
JOB #	J0221-0760

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system an for the overall structure. The design of the truss support structure including headers, beams, walls support structure including headers, beams, walls and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.co



Truss Placement Plan SCALE: 1/4" = 1'0"

▲ = Denotes Left End of Truss (Reference Engineered Truss Drawing)

= THD26-2 (Qty. 1) = HUS26 (Qty. 8)

		Products		
PlotID	Length	Product	Plies	Net Qty
GDH-3 (dropped)	13' 0"	1-3/4"x 11-7/8" LVL Kerto-S	2	2
GDH (dropped)	23' 0"	1-3/4"x 14" LVL Kerto-S	2	2

All Truss Reactions are Less than 3,000 lbs. Unless Noted Otherwise.

than 6,666 lbs. Omess rected otherwise.
Denotes Reaction Greater than 3,000 lbs.
Reaction / # of Studs

соттесн **ROOF & FLOOR TRUSSES & BEAMS**

Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

Bearing reactions less than or equal to 3000# are deemed to comply with the prescriptive Code requirements. The contractor shall refer to the attached Tables (derived from the prescriptive Code requirements) to determine the minimum foundation size and number of wood studs required to support reactions greater than 3000# but not greater than 15000#. A registered design professional shall be retained to design the support system for any reaction that exceeds those specified in the attached Tables. A registered design professional shall be retained to design the support system for all reactions that exceed 15000#.

Lenny Norris

LOAD CHART FOR JACK STUDS

(8ASÉD ON TABLÉS ROCES(1) & (b))

NUMBER OF LACK STUDS REQUIRED & EA END OF HEADER/GERDER END REACTION (AF TO) REQ'D STUDA FOR (3) ALY HEADER 1700 1 3400 1 2550 1 3400 2 6800 2 5100 2 5100 3 7650 3 10200 3 6800 4 10200 4 13600 4 8500 5 12750 5 17000 5 10200 6 15300 6 11900 7 13600 8

15300 9

Weaver Development Co. Inc.	COUNTY	Harnett
Lot 4 Atkins Farm	ADDRESS	Lot 4 Atkins Farm
Sinclair (190320B)	MODEL	Model
Seal Date	DATE REV. //	//
Quote #	DRAWN BY	DRAWN BY Lenny Norris
J0221-0760	SALESMAN	SALESMAN Lenny Norris

Quote ; Lot **SEAL DATE** JOB

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

BUILDER