

All Walls Shown Are Considered Load Bearing 1. Pl 2. C

Plumbing Drop Notes
 Plumbing drop locations shown are NOT exact. Contractor to verify ALL plumbing drop locations prior to setting Floor Trusses. Adjust spacing as needed not to exceed 24"oc.

	COMTECH ROOF & FLOOR ROOF & FLOOR RUSSES & BEAMS Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444							
	Bearing reactions less than or equal to 3000# are deemed to comply with the prescriptive Code requirements. The contractor shall refer to the attached Tables (derived from the prescriptive Code requirements) to determine the minimum foundation size and number of wood studs required to support reactions greater than 3000# but not greater than 15000#. A registered design professional shall be retained to design the support system for any reaction that exceeds those specified in the attached Tables. A registered design professional shall be retained to design the support system for all reactions that exceed 15000#.							
	NO BOAVH (AU 2) 1010 VM (AU 2) 1 1700 1 3400 2 5100 3 6800 4 8500 5 10200 6 11900 7 13600 8 15300 9		READER READER VEX.02 COMPLEX AUGUST VEX.02 COMPLEX AUGUST 25550 1 5100 2 7650 3 10200 4 12750 5 15300 6		NOTICE AND A REAL AND			
	COUNTY Harnett	ADDRESS Tanna Place	MODEL Floor	DATE REV. 01/07/21	DRAWN BY David Landry	SALESMAN Marshall Naylor		
	R Ben Stout Real Estate	ME Lot 31 Forest Ridge	The Ashville	ATE N/A	# Quote #	J1220-5670		
	BUI LDER	JOB NAME	PLAN	SEAL DATE	QUOTE #	JOB #		
	THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com							