


REVISIONS		
1	X	
2	X	
3	X	
4	X	

H&H  
Redud "B"  
Base + COP + 3CG  
Lot - Sub  
Roof Truss

SUMTER TRUSS PLANT  
P.O. BOX 1546  
SUMTER, SC 29151  
PHONE: (803) 778-1921  
FAX: (803) 773-4731



DRAWN BY  
JR  
DATE  
2/08/17  
JOB NUMBER  
XXXXXX  
SHEET NUMBER  
1 of 1

**ROOF TRUSS NOTES:**

DO NOT CUT, DRILL, NOTCH, OR OTHERWISE DAMAGE TRUSSES. Contact your BFS Representative for assistance PRIOR TO modifying any truss. **Espanol** - NO CORTE, PERFORE, HAGA MUESCAS O DAÑE LAS TRUSS. Contact your BFS Representative (GERCHAS DE MAJERA). **Contacta a su representante de BFS para asistencia ANTES de realizar cualquier modificación.**



- This Truss Placement Diagram is intended to serve as a guide for truss installation. The Diagram has been prepared by a qualified truss designer and is not an engineered drawing.
- The responsibilities of the Owner, Building Designer, Designer, and Erector shall be as follows: 1. The Designer shall provide the Truss Design and Truss Placement Diagram to the Owner. 2. The Owner shall provide the Truss Design and Truss Placement Diagram to the Erector. 3. The wood components shown on this diagram are to be used in dry service (moisture content < 19%) and non-load bearing applications. 4. The truss manufacturer shall be responsible for the design and fabrication of the trusses. 5. The Truss Designer shall provide Truss-to-Truss Connection Requirements. Any special or other connections shall be the responsibility of the Building Designer. 6. The Truss Placement Diagram and Truss Design Drawings are the property of Builders FirstSource and shall not be reproduced, copied, or used in whole or in part without the written consent of Builders FirstSource.
- In some cases, field framing may be required to adequately support the trusses. The foundation design, framing, and other details shall be the responsibility of the applicable building code and the responsibility of the Owner, Building Designer, and Contractor.
- Refer to the Milk, Piggyback Connection Detail for applicable for the project details and wind load category.
- The Contractor shall follow the SBGA, TTB, Pruttkon Separation Prevention and Solutions for truss attachment to non-load bearing walls and carefully follow the details to avoid gypsum wall board related issues.

TRUSSES MUST BE BRACED DURING INSTALLATION. FAILURE TO BRACE TRUSSES MAY RESULT IN INJURY OR DEATH. **Espanol** - TRUSSSES DEBERAN TENER UN SOPORTE DURING INSTALLATION. LA FALTA DE BRACER LAS TRUSSSES PUEDE RESULTAR EN LESIONES O MUERTE.

Trusses shall be installed in a braced manner meeting the following requirements: 1. Trusses shall be braced under construction, as indicated by high winds and present a possible safety hazard. The Contractor is responsible for recognizing adverse weather conditions and shall take appropriate action to protect the trusses. 2. BCSI INSTRUCTIONS SHALL BE FOLLOWED: BCSIB1 = Safe Truss Handling and Installation BCSIB2 = Truss Installation and Temporary Bracing BCSIB3 = Safe Truss Construction Loading BCSIB4 = Truss Damage and Modification Guidelines BCSIB5 = Truss Damage and Modification Guidelines BCSIB6 = Truss Damage and Modification Guidelines BCSIB7 = Multi-Ply Girders BCSIB8 = Truss Installation BCSIB9 = Post Frame Truss Installation BCSIB10 = Post Frame Truss Installation 3. Follow TPI Requirements for Long Span Trusses (>80').

HANGER TYPE	Qty	FASTENERS TO MEMBER	CARRYING MEMBER	CARRIED MEMBER
HTU-26	13	20-16d	20-10d x 1 1/2"	G02, 2d10, A14-17, A20

AI TIEDOWNS H10A UNLESS OTHERWISE NOTED	Product	Length	Net Qty
HDR-1	LVL	12' 0"	2
HDR-1	LVL	1 3/4" x 16" L, 9E Microlam	LVL 2 2



Rigid	Length	Product	Piles	Net Qty
HDR-1	12' 0"	LVL	2	2