



Products					
PlotID	Length	Product	Plies	Net Qty	Fab Type
J1	35' 0"	11 7/8" TJI@ 210	1	6	MFD
J2	31' 0"	11 7/8" TJI@ 210	1	12	MFD
J3	29' 0"	11 7/8" TJI@ 210	1	13	MFD
J4	29' 0"	11 7/8" TJI@ 210	2	2	MFD
J5	25' 0"	11 7/8" TJI@ 210	1	5	MFD
J6	24' 0"	11 7/8" TJI@ 210	1	1	MFD
J7	16' 0"	11 7/8" TJI@ 210	1	14	MFD
J8	15' 0"	11 7/8" TJI@ 210	1	1	MFD
J9	11' 0"	11 7/8" TJI@ 210	1	1	MFD
J10	10' 0"	11 7/8" TJI@ 210	1	3	MFD
RIM-1	16' 0"	1 1/8" x 11 7/8" TJ@ Rim Board	1	14	FF
Bk1	2' 0"	11 7/8" TJI@ 210	1	25	MFD

UFP MID-ATLANTIC, LLC
 A UNIVERSAL FOREST PRODUCTS COMPANY
 BURLINGTON, NC PHONE (800) 476-9356
 CHESAPEAKE, VA PHONE (800) 476-3190
 CONWAY, SC PHONE (800) 397-9572
 JEFFERSONGA PHONE (800) 648-4038
 PEARISBURG, VA PHONE (800) 397-9571

GENERAL NOTES:
 1.) TOP CHORD OF JOISTS ARE PAINTED RED AT NUMBERED END. PLACE PAINTED END AS NOTED ON PLAN.
 2.) FOLLOW SPECIAL SPACING AND LOCATION DIMENSIONS FOR EXTRAS OR SHIFTED JOISTS AS SHOWN ON PLAN.
 3.) ALL INTERIOR WALL PLATES MUST BE LEVEL WITH OUTSIDE WALL TOP PLATES.
 4.) DO NOT STACK CONSTRUCTION LOADS ON UN-BRACED JOISTS.
 5.) PROVIDE SOLID SUPPORT BELOW ALL BEAM AND HEADER BEARING POINTS IN WALL AND JOIST SPACES CONTINUOUS DOWN TO THE FOUNDATION.
 6.) LOCATE CRIPPLE STUDS IN JOIST SPACE DIRECTLY BELOW HEADER JACKS AT ALL FIRST FLOOR EXTERIOR DOOR LOCATIONS.
 7.) INSTALL NAILS IN ALL HOLES PROVIDED IN JOIST HANGERS EXCEPT AT BOTTOM CHORD SEAT. PLACE A DAB OF GLUE IN THE HANGER SEAT BEFORE SETTING JOISTS.
 8.) IMPORTANT NOTE! NO STRUCTURAL ANALYSIS OF CONVENTIONAL HEADERS HAS BEEN CONDUCTED IF NOT NOTED. THEY ARE CONSIDERED TO BE ADEQUATE TO SUPPORT THE APPLIED LOADS.

● Avoid Plumbing Drops

FIELD LOCATE PLUMBING DROPS/CAN LIGHTS, ETC... PRIOR TO JOIST SECUREMENT TO AVOID INTERFERENCE.

LAYOUT FOR 19.2" O/C

1= 19-3/16"	9= 172-13/16"
2= 38-3/8"	10= 192"
3= 57-5/8"	11= 211-3/16"
4= 76-13/16"	12= 230-3/8"
5= 96"	13= 249-13/16"
6= 115-3/16"	14= 268-13/16"
7= 134-3/8"	15= 288"
8= 153-5/8"	

FRAMER NOTE
 1. GLUE AND NAIL PLYWOOD SUBFLOOR TO BEAMS AND GIRDERS AT 6" O/C WHERE NO WALL IS ABOVE.
 2. FILL HANGER SEAT WITH GLUE BEFORE SETTING JOIST IN HANGER. FILL ROUND HOLES WITH NAILS.

CRITICAL !!
 INSTALL 2X4 SQUASH BLOCKS IN FLOOR TRUSS SPACE BELOW ALL EXTERIOR DOOR HEADER JACKS. CUT 1/16" TALLER THAN TRUSS.

FIELD VERIFY DIMENSIONS TO JOISTS LOCATED UNDER WALLS!!
1ST FLOOR LAYOUT

LOADING	DEFLECTION
ROOF LIVE 20 PSF	L/240
ROOF DEAD 20 PSF	L/180
FLOOR LIVE 40 PSF	L/480
FLOOR DEAD 10 PSF	L/240

Special Loading: _____

Customer: **RED DOOR HOMES**
 Job Name: **LEXINGTON**
 Date: 11/17/2021
 Scale: NTS
 Revision Date: _____
 Revision Date: _____

Lot #: _____
 Drawn By: EC
 Drawing Number: **21090965F1**