

, And	20-03-08			REMAIN WTIH THE CONTRACTOR.		FOF AUTOMIgers
		40-00-00			24) HUS26	
All stick frame loads from above MUST transfer to bearing walls or structural beams below (U.N.O.) Plumb Drops are estimated only. Trusses may need slight adjustment to provide full clearance while maintaining specified spacing.		ROOF TRUSS LAYOUT SCALE: 3/16" = 1'				RESIDENTIAL STRUCTURES, P.C. 3410 N. Devideon St. Charlotte, N.C. 28205 ##) ######## Seal For Structural Only##) ######### 
			Client:	rue Homes		
The	The Building Center, Inc.	<i>THE BUILDING CENTER, INC.</i> 2591 Jenkins Dairy Rd PH. (704) 824-8182 FAX. (704) 824-2232	Notes:		Job Desc: THE WAYNE - 2672	
Building					Site Information: Lot 18 WAG	
Center, Ir						
					Salesman: NA	Date: 04/01/2021
					Drafter: MSC	Job #: 21031298
THIS IS A TRUSS PLACEMENT DIAGRAM ONLY. These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing roof and floor system and for the overall structure. The design of the truss support structure including headers, beams,				SHOP DRAWING APPROVAL THIS LAYOUT IS THE SOLE SOURCE FOR FABRICATION OF TRUSSES AND VOIDS ALL PREVIOUS ARCHITECTURAL OR OTHER TRUSS LAYOUTS. REVIEW AND APPROVAL OF THIS LAYOUT MUST BE RECEIVED BEFORE ANY TRUSSES WILL BE BUILT. VERIFY ALL CONDITIONS TO INSURE AGAINST CHANGES THAT WILL RESULT IN EXTRA CHARGES TO YOU.		
and columns is the responsibility of the building designer. For general guidance regarding bracing, consult "Bracing Trusses" available from the Truss Plate Institute, 583 D'Onifrio Drive; Madison, WI 53179.				REVIEWED BY:	APPROVED BY:	DATE: