

Dimension Notes

1. All exterior wall to wall dimensions are to face of sheathing unless noted otherwise
2. All interior wall dimensions are to face of frame wall unless noted otherwise
3. All exterior wall to truss dimensions are to face of frame wall unless noted otherwise

All Walls Shown Are Considered Load Bearing

Plumbing Drop Notes

1. Plumbing drop locations shown are NOT exact.
2. Contractor to verify ALL plumbing drop locations prior to setting Floor Trusses.
3. Adjust spacing as needed not to exceed 24"oc.

Connector Information					Nail Info	ormation
Sym	Product	Manuf	Qty	Supported Member	Header	Truss
	HUS410	USP	14	NA	16d/3-1/2"	16d/3-1/2"

	Products						
PlotID	Length	Product	Plies	Net Qty			
BM1	12' 0"	1-3/4"x 16" LVL Kerto-S	2	2			
BM2	15' 0"	1-3/4"x 16" LVL Kerto-S	2	2			
BM3	12' 0"	2x10 SPF No.2	2	2			
GDH	12' 0"	2x12 SPF No.2	2	2			



= Indicates Left End of Truss
(Reference Engineered Truss Drawing)
Do NOT Erect Truss Backwards

соттесн
ROOF & FLOOR TRUSSES & BEAMS
Reilly Road Industrial Park

Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

Bearing reactions less than or equal to 3000# are leemed to comply with the prescriptive Code requirements. The contractor shall refer to the attached Tables (derived from the prescriptive Code requirements) to determine the minimum foundation size and number of wood studs required to support reactions greater than 3000# but not greater than 15000#. A registered design professional shall be retained to design the support system for any reaction that exceeds those specified in the attached fables. A registered design professional shall be retained to design the support system for all reactions that exceed 15000#.

Signature David Landry

David Landry

•

LOAD CHART FOR JACK STUDS
(BASED ON TABLES R502.5(1) & (b))

NUM	MBER C	STUDS R		A END O	F
END REACTION (UP TO)	REQ'D STUDS FOR (2) PLY HEADER	END REACTION (UP TO)	REQ'D STUDS FOR (3) PLY HEADER	END REACTION (UP TO)	REG'D STUDS FOR
700	1	2550	1	3400	
400	2	5100	2	6800	
5100	3	7650	3	10200	
800	4	10200	4	13600	4
3500	5	12750	5	17000	
0020	6	15300	6		
1900	7				
3600	8				
5300	9				

ic. CITY / CO. Harnett / Harnett	ADDRESS Lot 6 West Park	MODEL Floor	DATE REV . 03/02/21	DRAWN BY David Landry	SALES REP. Lenny Norris
ment Co. Inc.					

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.

These trusses are designed as individual building components to be incorporated into the building design at the specification of the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

Weaver Developr