Mark Morris, P.E.

#126, 1317-M, Summerville, SC 29483 843 209-5784, Fax (866)-213-4614

The truss drawing(s) listed below have been prepared by **Atlantic Building Components** under my direct supervision based on the parameters provided by the truss designers.

AST #: 26912 JOB: 21-3147-R01 JOB NAME: LOT 1156 CARRIAGE CIRCLE Wind Code: 37 Wind Speed: Vult= 130mph Exposure Category: B Mean Roof Height (feet): 23

22 Truss Design(s)

Trusses:

J01, J02, PB01, PB02, R01, R02, R03, R03A, R04, R05, R06, R07, R08, R09, R10, R11, VT01, VT02, VT03, VT04, VT05, VT06



Warning !--- Verify design parameters and read notes before use.

This design is based only upon parameters shown, and is for an individual building component to be installed and loaded vertically. Applicability of design parameters and proper incorporation of component is responsibility of building designer – not truss designer or truss engineer. Bracing shown is for lateral support of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 *National Design Standard for Metal Plate Connected Wood Truss Construction* and BCSI 1-03 Guide to *Good Practice for*



LOADING (ps TCLL (roof) Snow (Pf) TCDL BCLL BCDL	f) 20.0 20.0 10.0 0.0 * 10.0	SPACING-2-0-0Plate Grip DOL1.15Lumber DOL1.15Rep Stress IncrYESCode IRC2018/TPI2014	CSI. TC 0.12 BC 0.08 WB 0.05 Matrix-R	DEFL. Vert(LL) Vert(CT) Horz(CT)	in (l -0.00 -0.00 0.00	loc) 1 1 5	l/defl n/r n/r n/a	L/d 180 80 n/a	PLATES MT20 Weight: 23 lb	GRIP 244/190 FT = 0%
LUMBER- TOP CHORD BOT CHORD WEBS OTHERS	2x4 SP No.2 2x4 SP No.3 2x4 SP No.3 2x4 SP No.3 2x4 SP No.3			BRACING- TOP CHORD BOT CHORD	Structur end vert Rigid ce MiTek be inst	ral wo rticals eiling c reco stalled	ood shea directly mmends during guide.	athing direct applied or 1 s that Stabil truss erectio	tly applied or 4-10-8 c 10-0-0 oc bracing. izers and required cro on, in accordance with	nc purlins, except

REACTIONS. (lb/size) 7=151/4-10-8 (min. 0-1-8), 5=76/4-10-8 (min. 0-1-8), 6=200/4-10-8 (min. 0-1-8) Max Horz 7=74(LC 14) Max Uplift7=-7(LC 10), 5=-18(LC 14), 6=-80(LC 14)

Max Grav 7=219(LC 21), 5=106(LC 21), 6=274(LC 21)

FORCES. (Ib) - Max. Comp./Max. Ten. - All forces 250 (Ib) or less except when shown.

NOTES-(13-14)

- 1) Wind: ASCE 7-16; Vult=130mph (3-second gust) Vasd=103mph; TCDL=5.0psf; BCDL=5.0psf; h=23ft; Cat. II; Exp B; Enclosed; MWFRS (envelope) gable end zone and C-C Exterior(2) zone; end vertical left exposed; porch left exposed;C-C for members and forces & MWFRS for reactions shown; Lumber DOL=1.60 plate grip DOL=1.60
- 2) Truss designed for wind loads in the plane of the truss only. For studs exposed to wind (normal to the face), see Standard Industry Gable End Details as applicable, or consult qualified building designer as per ANSI/TPI 1
- 3) TCLL: ASCE 7-16; Pr=20.0 psf (roof LL: Lum DOL=1.15 Plate DOL=1.15); Pf=20.0 psf (Lum DOL=1.15 Plate DOL=1.15); Is=1.0; Rough Cat B; Partially Exp.; Ce=1.0; Cs=1.00; Ct=1.10
- 4) Unbalanced snow loads have been considered for this design.
- 5) This truss has been designed for greater of min roof live load of 12.0 psf or 2.00 times flat roof load of 20.0 psf on overhangs
- non-concurrent with other live loads. Gable requires continuous bottom chord bearing.
- 7) Truss to be fully sheathed from one face or securely braced against lateral movement (i.e. diagonal web).
- Gable studs spaced at 2-0-0 oc.
- 10) * This truss has been designed for a live load of 30.0psf on the bottom chord in all areas where a rectangle 3-6-0 tall by 1-0-0 wide will the CAROUS
 11) Provide mechanical connection (by others) of true tails PROFESS/ 11) Provide mechanical connection (by others) of truss to bearing plate capable of withstanding 7 lb uplift at joint 7, 18 lb uplift at joint 5 and

SEAL

28147

NOINE

K. MORR in minine

6/3/2021

- 80 lb uplift at joint 6. 12) This truss is designed in accordance with the 2018 International Residential Code sections R502.11.1 and R802.10.2 and referenced
- standard ANSI/TPI 1. 13) Graphical web bracing representation does not depict the size, type or the orientation of the brace on the web. Symbol only indicates
- Annunderstand that the member must be braced.
- 14) Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.

LOAD CASE(S) Standard









vertically. Applicability of design parameters and read notes before use. This design is based only upon parameters shown, and is for an individual obliding component to be instance and roaded of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 *National Design Standard for Metal Plate Connected Wood Trusse Construction* and BCSI 1-03 Guide to *Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses* from Truss Plate Institute, 583 D'Onorio Drive, Madison, WI 53719.

Job	Truss	Truss Type	Qty	Ply	LOT 1156 CARRIAGE CIRCLE 138 SPRUCE	HOLLOW CIRCLE SPRING LAK	E, I	
21-3147-R01	R01	GABLE	1	1	Job Reference (optional)	# 26912		
8.430 s Feb 12 2021 MiTek Industries, Inc. Fri Jun 4 20:50:33 2021 Page 2 ID:MsMZ7fuyNIJd5IEFbR85JwyPq?q-90RBVWgHC0aE57gOodFMwqEh2L32rBJZP?Ag7?z9ZKa								

NOTES- (16-17)

15) This truss is designed in accordance with the 2018 International Residential Code sections R502.11.1 and R802.10.2 and referenced standard ANSI/TPI 1.

16) Graphical web bracing representation does not depict the size, type or the orientation of the brace on the web. Symbol only indicates that the member must be braced. 17) Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.

LOAD CASE(S) Standard



6/3/2021



responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 National Design Standard for Metal Plate Connected Wood Truss Construction and BCSI 1-03 Guide to Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.



responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 National Design Standard for Metal Plate Connected Wood Truss Construction and BCSI 1-03 Guide to Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.



Job	Truss	Truss Type	Qty	Ply	LOT 1156 CARRIAGE CIRCLE 138 SPRUCE H	HOLLOW CIRCLE SPRING LA	ÂKE, I
21-3147-R01	R03A	Common	1	1	Job Reference (optional)	# 26912	
					8 430 c Ech 12 2021 MiTck Industries Inc. Er	i lun 4 20.50.37 2021 Page 2	ົ

ID:MsMZ7fuyNIJd5IEFbR85JwyPq?q-1nhiLujoGF4gZI_A1TJI4gPAmyDqnuZ9Kd8uGnz9ZKW

Graphical web bracing representation does not depict the size, type or the orientation of the brace on the web. Symbol only indicates that the member must be braced.
 Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.

LOAD CASE(S) Standard





Job	Truss	Truss Type	Qty	Ply	LOT 1156 CARRIAGE CIRCLE 138 SPRUCE HOLLOW CIRCLE SPRING LA	ÅΚΕ,
21-3147-R01	R04	COMMON	5	1	Job Reference (optional) # 26912	
					9 420 a Eab 12 2021 MiTak Industrian Ina Eri Jun 4 20:E0:20 2021 Daga 2	5

8430 s Feb 12 2021 Milek Industres, Inc. Fn Jun 4 20:03:39 2021 Page 2 ID:MsMZ7fuyNIJd5IEFbR85JwyPq?q-_ApSIZk2osLOp28Y9uLm65UWImvHFo3Rxx7kf29ZKU 11) Graphical web bracing representation does not depict the size, type or the orientation of the brace on the web. Symbol only indicates that the member must be braced. 12) Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.

LOAD CASE(S) Standard



6/3/2021



of individual web members only. Additional temporary bracing to ensure stability during construction is the responsibility of the erector. Additional permanent bracing of the overall structure is the responsibility of the building designer. For general guidance regarding fabrication, quality control, storage, delivery, erection and bracing, consult ANSI/TPI 1 National Design Standard for Metal Plate Connected Wood Truss Construction and BCSI 1-03 Guide to Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.

Job	Truss	Truss Type	Qty	Ply	LOT 1156 CARRIAGE CIRCLE 138 SPRUC	E HOLLOW CIRCLE SPRING LAKE,		
21-3147-R01	R05	GABLE	1	1	Job Reference (optional)	# 26912		
8.430 s Feb 12 2021 MiTek Industries, Inc. Fri Jun 4 20:50:41 2021 Page 2 ID:MsMZ7fuyNIJd5IEFbR85JwyPq?q-wZwCAFmJKTb62MHxGJOEFWa2AZn1jolkFF65PYz9ZKS								

NOTES- (16-17)

15) This truss is designed in accordance with the 2018 International Residential Code sections R502.11.1 and R802.10.2 and referenced standard ANSI/TPI 1.

16) Graphical web bracing representation does not depict the size, type or the orientation of the brace on the web. Symbol only indicates that the member must be braced. 17) Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.

LOAD CASE(S) Standard



6/3/2021



Job	Truss	Truss Type	Qty	Ply	LOT 1156 CARRIAGE CIRCLE 138 S	PRUCE HOLLOW CIRCLE SPRING LAKE,
21-3147-R01	R06	Common Girder	1	2	Job Reference (optional)	# 26912
					0.420 a Eab 42.2024 MiTals Industria	a Ina Eri lun 4 20:50:42 2021 Daga 2

ID:MsMZ7fuyNIJd5IEFbR85JwyPq?q-sx2zbxnZs5rqHgRJOjQiKxfN5NHyBYi1iZbCUQz9ZKQ

12) Graphical web bracing representation does not depict the size, type or the orientation of the brace on the web. Symbol only indicates that the member must be braced. 13) Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.

LOAD CASE(S) Standard

1) Dead + Snow (balanced): Lumber Increase=1.15, Plate Increase=1.15

Uniform Loads (plf)

Vert: 1-3=-60, 3-5=-60, 6-10=-20

Concentrated Loads (lb) Vert: 7=-1389(B) 9=-1498(B) 11=-1498(B) 12=-1498(B) 13=-1498(B) 14=-1389(B) 15=-1389(B)



6/3/2021





Job	Truss	Truss Type	Qty	Ply	LOT 1156 CARRIAGE CIRCLE 138 SPRUCE HOLLOW CIRCLE SPRING LAKE,
21-3147-R01	R08	Common Supported Gable	1	1	Job Reference (optional) # 26912
					8.430 s Feb 12 2021 MiTek Industries, Inc. Fri Jun 4 20:50:45 2021 Page 2

ID:MsMZ7fuyNIJd5IEFbR85JwyPq?q-oKAj0dppOi5XXzbiV8SAPMkksA9YfdQKAt4JYJz9ZKO

14) Graphical web bracing representation does not depict the size, type or the orientation of the brace on the web. Symbol only indicates that the member must be braced. 15) Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.

LOAD CASE(S) Standard



6/3/2021



Job	Truss	Truss Type	Qty	Ply	LOT 1156 CARRIAGE CIRCLE 138 SPRUCE	HOLLOW CIRCLE SPRING LAK
21-3147-R01	R09	Attic	9	1	Job Reference (optional)	# 26912
					Job Reference (optional)	

ID:MsMZ7fuyNIJd5IEFbR85JwyPq?q-HWk5DzqR80D087Au3szPyaHIUaKZO_qT0Xps4lz9ZKN

NOTES- (13-14)

11) This truss is designed in accordance with the 2018 International Residential Code sections R502.11.1 and R802.10.2 and referenced standard ANSI/TPI 1.

12) Attic room checked for L/360 deflection.

13) Graphical web bracing representation does not depict the size, type or the orientation of the brace on the web. Symbol only indicates that the member must be braced. 14) Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.

LOAD CASE(S) Standard



6/3/2021



Plate Connected Wood Truss Construction and BCSI 1-03 Guide to Good Practice for Handling, Installing & Bracing of Metal Plate Connected Wood Trusses from Truss Plate Institute, 583 D'Onofrio Drive, Madison, WI 53719.

Job	Truss	Truss Type	Qty	Ply	LOT 1156 CARRIAGE CIRCLE 138 SPRUC	E HOLLOW CIRCLE SPRING LAKE, I		
21-3147-R01	R10	GABLE	1	1	Job Reference (optional)	# 26912		
8.430 s Feb 12 2021 MiTek Industries, Inc. Fri Jun 4 20:50:48 2021 Page 2 ID:MsMZ7fuyNIJd5IEFbR85JwyPq?q-DvrseerigdT6ORKHAH0t1?M7vO9Osw1msrlz9ez9ZKL								

NOTES- (16-17)

- 12) Bottom chord live load (40.0 psf) and additional bottom chord dead load (0.0 psf) applied only to room. 36-38, 34-36, 32-34, 30-32, 28-30, 25-28, 23-25, 22-23 13) Provide mechanical connection (by others) of truss to bearing plate capable of withstanding 290 lb uplift at joint 42, 131 lb uplift at joint 39, 125 lb uplift at joint 21, 282 lb uplift
- at joint 18, 146 lb uplift at joint 40, 308 lb uplift at joint 41, 146 lb uplift at joint 20 and 306 lb uplift at joint 19.
- 14) This truss is designed in accordance with the 2018 International Residential Code sections R502.11.1 and R802.10.2 and referenced standard ANSI/TPI 1.
- 15) Attic room checked for L/360 deflection.
- 16) Graphical web bracing representation does not depict the size, type or the orientation of the brace on the web. Symbol only indicates that the member must be braced. 17) Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.

LOAD CASE(S) Standard



6/3/2021

Job	Truss	Truss Type		Qty	Ply	LOT 1156 CAF	RRIAGE CIRCLE 1	138 SPRUCE HOLLO	W CIRCLE SPRING L	AKE, I
21-3147-R01	R11	Monopitch Supported	l Gable	1		1		#	4 26012	
						Job Reference	ce (optional)	#	20912 1 20:50:40 2021 Baga :	1
				ID:MsMZ7fuyNIJ	d5IEFbF	8.430 S Feb R85JwyPq?q-h5l	PEs_sKRxbz?bv	rtk_X6aCvQmnWf	bQ5w4V2Wh4z9ZKI	ĸ
			-0-10-8 0-10-8	<u>8-4-0</u> 8-4-0						
			0.00	0.10						_
				2x4	П				Scale = 1:61.9	9
		1			6					
				2-4	Ø					
				2.44						
			12.00 12	5						
			2x4							
				4						
		12	2x4		14/2					
		+++++++++++++++++++++++++++++++++++++++	3		× v					
		`3v		Втз						
				ST2						
]	1 ² ST1							
		15	w							
		2-9	WZ							
		J								
			11 10	9 8	7					
			3x6 3x4 =	2x4 2x4	2x4	l				
			1							
Plate Offsets (X Y) [2]	0-1-4 0-1-81		1							_
LOADING (psf)										=
TCLL (roof) 20.0	Plate Grip DOL	2-0-0	CSI. TC 0.22	Vert(LL)	ın 0.00	(loc) l/defi 1 n/r	L/d 180	MT20	GRIP 244/190	
Snow (Pf) 20.0 TCDL 10.0	Lumber DOL	1.15	BC 0.11	Vert(CT)	0.00	1 n/r	80			
BCLL 0.0 *	Code IRC2018/TF	YES 12014	WB 0.15 Matrix-P	Horz(CT)	-0.00	/ n/a	n/a	Weight: 84 lb	FT = 0%	
BCDL 10.0								5		-
TOP CHORD 2x4 SP N	o.2			TOP CHORD	Struct	ural wood shea	athing directly a	pplied or 6-0-0 o	c purlins, except	
BOT CHORD 2x4 SP N	0.3				end ve	erticals.	applied or 10 0			
OTHERS 2x4 SP N	0.3			WEBS	1 Row	at midpt	6-7, 5-8	-0 oc bracing.		
					MiTe	k recommends	s that Stabilizer	s and required cr	ross bracing	
					be in	stalled during f	truss erection, i	in accordance wi	th Stabilizer	
REACTIONS. All bear	ings 8-4-0.					guide.				
(lb) - Max Horz Max Uplit	t 11=287(LC 12) t All uplift 100 lb or less at	ioint(s) 7 except 1	1=-196(LC 10). 9=	-106(LC 12). 10=-	484(LC	12). 8=-114(L	С			
May Croy	12)	a at ident(a) \overline{a} avec	vot 11-E08(I C 12)	0-268/1 C 20) 1/)	C 20) 8-202/				
	20)	s at joint(s) / exce	pt 11=596(LC 12)	, 9–200(LC 20), I	J-302(L	-0 20), 0-302(10			
FORCES (Ib) Max C	mn/Max Ten All forces '	250 (lb) or less ex	cent when shown							
TOP CHORD 2-11=-5	90/467, 2-3=-359/295, 3-4=	-263/201	cept when shown.							
BOT CHORD 10-11=- WEBS 2-10=-3	303/235 83/495									
	00/400									
NOTES- (12-13) 1) Wind: ASCE 7-16: Vu	It=130mph (3-second qust)	Vasd=103mph ⁻ T(CDI =5 0psf: BCDI	=5 0nsf: h=23ft: (Cat II: F	xn B. Enclose	d MWERS			
(envelope) gable end	zone and C-C Exterior(2) zo	one; end vertical le	eft exposed;C-C fo	r members and for	rces & I	WFRS for rea	actions			
 shown; Lumber DOL= 2) Truss designed for w 	1.60 plate grip DOL=1.60 ind loads in the plane of the	truss only For st	uds exposed to wi	nd (normal to the t	face) s	ee Standard In	dustry			
Gable End Details as	applicable, or consult qualif	ied building design	ner as per ANSI/T	PI 1.	1400), 0		ddolly			
3) TCLL: ASCE 7-16; Pr Cat B: Partially Exp : (=20.0 psf (roof LL: Lum DO Ce=1 0 [.] Cs=1 00 [.] Ct=1 10	L=1.15 Plate DOL	=1.15); Pf=20.0 ps	of (Lum DOL=1.15	Plate D)OL=1.15); ls=	1.0; Rough	MUMMINI		
4) This truss has been d	esigned for greater of min ro	oof live load of 12.	0 psf or 2.00 times	s flat roof load of 2	0.0 psf	on overhangs	when a	ATH CARO	1111	
5) Gable requires contin	ther live loads. uous bottom chord bearing.						Mult	OFESSION	No line	
6) Truss to be fully sheat	thed from one face or secur	ely braced against	t lateral movement	t (i.e. diagonal web	o).		IIII	our va		
 Gable studs spaced a This truss has been d 	t 2-0-0 oc. esigned for a 10.0 psf botto	m chord live load	nonconcurrent with	n anv other live loa	ads.			SEAL		
9) * This truss has been	designed for a live load of 3	0.0psf on the bott	om chord in all are	eas where a rectar	ngle 3-6	-0 tall by 1-0-0	wide will fit	28147		
10) Provide mechanical	nord and any other member connection (by others) of tru	s, with BCDL = 10 iss to bearing plat	e capable of withs	tanding 100 lb upli	ift at ioi	nt(s) 7 except (jt=lb) 📜 🦄	Shin a	In	
11=196, 9=106, 10=	484, 8=114.	40 Intern - 1 1 -		5 19 - 2p	P2	· · · · · · · · · · · · · · · · · · ·	"Inthe	PL GINEE	Butte	
standard ANSI/TPI 1	a in accordance with the 20	no international R	esidential Code se	ections K502.11.1	and R8	02.10.2 and re	elerencea (4)	MA K. MONIN	Nr.	
								6/3/2021		
Attinuind he Wadh ?	n nanomotons and used used	ofore use This desire	m is based only we	noromotors shows -	nd is for-	on individual t	Iding commenced t	U/J/2U2I	ondod	

Job	Truss	Truss Type	Qty	Ply	LOT 1156 CARRIAGE CIRCLE 138 SPRUCE HOLLOW CIRCLE SPRING L/	ĀKE,
21-3147-R01	R11	Monopitch Supported Gable	1	1	Job Reference (optional) # 26912	
					8 430 s Eph 12 2021 MiTok Industrios, Inc. Eri, Jun 4 20:50:40 2021, Page 2	2

ID:MsMZ7fuyNIJd5IEFbR85JwyPq?q-h5PEs_sKRxbz?bvTk_X6aCvQmnWfbQ5w4V2Wh4z9ZKK

12) Graphical web bracing representation does not depict the size, type or the orientation of the brace on the web. Symbol only indicates that the member must be braced. 13) Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.

LOAD CASE(S) Standard



6/3/2021



6/3/2021



6/3/2021





NOTES- (9-10)

- 1) Unbalanced roof live loads have been considered for this design.
- 2) Wind: ASCE 7-16; Vult=130mph (3-second gust) Vasd=103mph; TCDL=5.0psf; BCDL=5.0psf; h=23ft; Cat. II; Exp B; Enclosed; MWFRS (envelope) gable end zone and C-C Exterior(2) zone;C-C for members and forces & MWFRS for reactions shown; Lumber DOL=1.60 plate grip DOL=1.60
- 3) TCLL: ASCE 7-16; Pr=20.0 psf (roof LL: Lum DOL=1.15 Plate DOL=1.15); Pf=20.0 psf (Lum DOL=1.15 Plate DOL=1.15); Is=1.0; Rough Cat B; Partially Exp.; Ce=1.0; Cs=1.00; Ct=1.10
- 4) Gable requires continuous bottom chord bearing.
- 5) This truss has been designed for a 10.0 psf bottom chord live load nonconcurrent with any other live loads.
- 6) * This truss has been designed for a live load of 30.0psf on the bottom chord in all areas where a rectangle 3-6-0 tall by 1-0-0 wide will fit between the bottom chord and any other members.
- 7) Provide mechanical connection (by others) of truss to bearing plate capable of withstanding 45 lb uplift at joint 1 and 45 lb uplift at joint 3. 8) This truss is designed in accordance with the 2018 International Residential Code sections R502.11.1 and R802.10.2 and referenced
- standard ANSI/TPI 1. 9) Graphical web bracing representation does not depict the size, type or the orientation of the brace on the web. Symbol only indicates that
- b) Graphical web bracing representation does not depict the size, type or the orientation of the brace on the web. Symbol only indicates that the member must be braced.
- 10) Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.

LOAD CASE(S) Standard





NOTES- (9-10)

- 1) Unbalanced roof live loads have been considered for this design.
- 2) Wind: ASCE 7-16; Vult=130mph (3-second gust) Vasd=103mph; TCDL=5.0psf; BCDL=5.0psf; h=23ft; Cat. II; Exp B; Enclosed; MWFRS (envelope) gable end zone and C-C Exterior(2) zone;C-C for members and forces & MWFRS for reactions shown; Lumber DOL=1.60 plate grip DOL=1.60
- 3) TCLL: ASCE 7-16; Pr=20.0 psf (roof LL: Lum DOL=1.15 Plate DOL=1.15); Pf=20.0 psf (Lum DOL=1.15 Plate DOL=1.15); Is=1.0; Rough Cat B; Partially Exp.; Ce=1.0; Cs=1.00; Ct=1.10
- 4) Gable requires continuous bottom chord bearing.
- 5) This truss has been designed for a 10.0 psf bottom chord live load nonconcurrent with any other live loads.
- 6) * This truss has been designed for a live load of 30.0psf on the bottom chord in all areas where a rectangle 3-6-0 tall by 1-0-0 wide will fit between the bottom chord and any other members.
- 7) Provide mechanical connection (by others) of truss to bearing plate capable of withstanding 31 lb uplift at joint 1 and 31 lb uplift at joint 3. 8) This truss is designed in accordance with the 2018 International Residential Code sections R502.11.1 and R802.10.2 and referenced
- standard ANSI/TPI 1. 9) Graphical web bracing representation does not depict the size, type or the orientation of the brace on the web. Symbol only indicates that
- 9) Graphical web bracing representation does not depict the size, type or the orientation of the brace on the web. Symbol only indicates that the member must be braced.
- 10) Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.

LOAD CASE(S) Standard





FORCES. (Ib) - Max. Comp./Max. Ten. - All forces 250 (Ib) or less except when shown.

NOTES- (9-10)

- 1) Unbalanced roof live loads have been considered for this design.
- 2) Wind: ASCE 7-16; Vult=130mph (3-second gust) Vasd=103mph; TCDL=5.0psf; BCDL=5.0psf; h=23ft; Cat. II; Exp B; Enclosed; MWFRS (envelope) gable end zone and C-C Exterior(2) zone;C-C for members and forces & MWFRS for reactions shown; Lumber DOL=1.60 plate grip DOL=1.60
- 3) TCLL: ASCE 7-16; Pr=20.0 psf (roof LL: Lum DOL=1.15 Plate DOL=1.15); Pf=20.0 psf (Lum DOL=1.15 Plate DOL=1.15); Is=1.0; Rough Cat B; Partially Exp.; Ce=1.0; Cs=1.00; Ct=1.10
- 4) Gable requires continuous bottom chord bearing.
- 5) This truss has been designed for a 10.0 psf bottom chord live load nonconcurrent with any other live loads.
- 6) * This truss has been designed for a live load of 30.0psf on the bottom chord in all areas where a rectangle 3-6-0 tall by 1-0-0 wide will fit between the bottom chord and any other members.
- 7) Provide mechanical connection (by others) of truss to bearing plate capable of withstanding 16 lb uplift at joint 1 and 16 lb uplift at joint 3. 8) This truss is designed in accordance with the 2018 International Residential Code sections R502.11.1 and R802.10.2 and referenced
- standard ANSI/TPI 1. 9) Graphical web bracing representation does not depict the size, type or the orientation of the brace on the web. Symbol only indicates that
- b) Graphical web bracing representation does not depict the size, type or the orientation of the brace on the web. Symbol only indicates that the member must be braced.
- 10) Bearing symbols are only graphical representations of a possible bearing condition. Bearing symbols are not considered in the structural design of the truss to support the loads indicated.

LOAD CASE(S) Standard

