

Dimension Notes

1. All exterior wall to wall dimensions are to face of sheathing unless noted otherwise
2. All interior wall dimensions are to face of frame wall unless noted otherwise
3. All exterior wall to truss dimensions are to face of frame wall unless noted otherwise

All Walls Shown Are Considered Load Bearing

Plumbing Drop Notes

1. Plumbing drop locations shown are NOT exact.
2. Contractor to verify ALL plumbing drop locations prior to setting Floor Trusses.
3. Adjust spacing as needed not to exceed 24"oc.

	Connector Information				Nail Information		
Sym	Product Manuf Qty Supported Member				Header	Truss	
	HUS410	USP	22	NA	16d/3-1/2"	16d/3-1/2"	
	THDH412	USP	1	NA	16d /3-1/2"	16d /3-1/2"	

		Products			
PlotID	Length	Product	Plies	Net Qty	Fab Type
BM1	12' 0"	1-3/4"x 16" LVL Kerto-S	2	2	FF
BM2	15' 0"	1-3/4"x 16" LVL Kerto-S	2	2	FF
BM3	12' 0"	2x10 SPF No.2	2	2	FF
GDH	20' 0"	1-3/4"x 14" LVL Kerto-S	2	2	FF

Truss Placement Plan
Scale: 1/4"=1'

ROOF & FLOOR TRUSSES & BEAMS

Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787

Fax: (910) 864-4444

Bearing reactions less than or equal to 3000# are deemed to comply with the prescriptive Code requirements. The contractor shall refer to the attached Tables (derived from the prescriptive Code requirements) to determine the minimum foundation size and number of wood studs required to support reactions greater than 3000# but not greater than 15000#. A registered design professional shall be retained to design the support system for any reaction that exceeds those specified in the attacher Tables. A registered design professional shall be retained to design the support system for all reactions that exceed 15000#.

ure David Landry

David Landry

LOAD CHART FOR JACK STUDS

	(6)	ASED (ON TABLE:	S R502	5(t) & (b))	
NU	WBER C)F JACI	K STUDS A HEADERA			A END	OF
END REACTION (UP 10)	REQ10 STUBS FOR (2) PLY HEADER		END REACTION (UP TO)	REQ16 STUBS FOR (3) ALY HEABER		ENG REACTION (UP TO)	REQUESTUDS FOR
1700	1		2550	1		3400	0 1
3400	2		5100	2		6800	0 2
5100	3		7650	3		1020	0 3
6800	4		10200	4		1360	0 4
8500	5		12750	5		1700	0 5
10200	6		15300	6			
11900	7						
13600	8						
15300	9						

Regency Homes	CITY / CO.	CI TY / CO. Erwin / Harnett	10200 11900 13600 15300
Lot 3 Walker Farm	ADDRESS	Wire Rd.	6 7 8 9
Hickory II / GR	MODEL	Floor	15300
	DATE REV. 09/01/21	09/01/21	0 6
	DRAWN BY	DRAWN BY David Landry	
J0921-5281	SALES REP. Bob Lewis	Bob Lewis	

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.
These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

SEAL DATE

QUOTE

JOB NAME

BUILDER