


All Walls Shown Are Considered Load Bearing

Roof Area = 1561.6 sq.ft. Ridge Line = 52.07 ft. Hip Line = 0 ft. Horiz. OH = 101.69 ft. Raked OH = 156.66 ft. Decking = 54 sheets



	Conne	ctor Info	Nail Information			
Sym	Product	Product Manuf Qty Supported Member Header		Truss		
	HUS26	USP	12	NA	16d/3-1/2"	16d/3-1/2"
3	THDH210-3	USP	1	Varies	16d/3-1/2"	16d/3-1/2"

		Products			
PlotID	Length	Product	Plies	Net Qty	Fab Type
BM1	12' 0"	1-3/4"x 16" LVL Kerto-S	2	2	FF
BM2	15' 0"	1-3/4"x 16" LVL Kerto-S	2	2	FF
GDH	20' 0"	1-3/4"x 11-7/8" LVL Kerto-S	2	2	FF





Reilly Road Industrial Park Fayetteville, N.C. 28309 Phone: (910) 864-8787 Fax: (910) 864-4444

Bearing reactions less than or equal to 3000# are leemed to comply with the prescriptive Code equirements. The contractor shall refer to the attached Tables (derived from the prescriptive Code equirements) to determine the minimum foundation size and number of wood studs required to support eactions greater than 3000# but not greater than 15000#. A registered design professional shall be etained to design the support system for any eaction that exceeds those specified in the attached Tables. A registered design professional shall be etained to design the support system for all eactions that exceed 15000#.

David Landry

David Landry

LOAD CHART FOR JACK STUDS

	(3	ASED.	CH	N TABLE:	5 R502	5(1) &	(b))		
NU	MBER C	JE JAC		STUDS R (EADER/)			EA END	OF	
END REACTION (UP 10)	REQ10 STUBS FOR (2) PLY HEADER			END REACTION (AF TO)	REQ15 STUDS FOR (3) ALY PEADER		END REACTION (UP TO)		REQ10 STUDS FOR
1700	1			2550	1		3400	0	1
3400	2			5100	2		6800	5	2
5100	3			7650	3		1020	0	3
6800	4			10200	4		1360	0	4
8500	5			12750	5		1700	0	5
10200	6			15300	6				
11900	7								
13600	8								
15300	9								
	1	- 1				- 1			

Regency Homes	CI TY / CO.	CI TY / CO. Erwin / Harnett	13600 15300
Lot 3 Walker Farm	ADDRESS	Wire Rd.	8 9
Hickory II / GR	MODEL	Roof	
	DATE REV. 09/01/21	09/01/21	
	DRAWN BY	DRAWN BY David Landry	
J0921-5280	SALES REP. Bob Lewis	Bob Lewis	

THIS IS A TRUSS PLACEMENT DIAGRAM ONLY.
These trusses are designed as individual building components to be incorporated into the building design at the specification of the building designer. See individual design sheets for each truss design identified on the placement drawing. The building designer is responsible for temporary and permanent bracing of the roof and floor system and for the overall structure. The design of the truss support structure including headers, beams, walls, and columns is the responsibility of the building designer. For general guidance regarding bracing, consult BCSI-B1 and BCSI-B3 provided with the truss delivery package or online @ sbcindustry.com

SEAL DATE

QUOTE 7

JOB NAME

BUILDER